



# GL300M Series @Track Air Interface Protocol

EGPRS/LTE Cat-M1/LTE Cat-NB1/GNSS Tracker

QSZTRACGL300MAN0701

Version: 7.01

*International Telematics Solutions Innovator*

[www.queclink.com](http://www.queclink.com)

<b>Document Title</b>	GL300M Series @Track Air Interface Protocol
<b>Version</b>	7.01
<b>Date</b>	2019-09-16
<b>Status</b>	Released
<b>Document Control ID</b>	QSZTRACGL300MAN0701

**General Notes**

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

**Copyright**

This document contains proprietary technical information which is the property of Queclink. Copying of this document, distribution to others or using or communication of the contents thereof is forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of a patent grant or the registration of a utility model or design. All specifications supplied herein are subject to change without notice at any time.

**Copyright © Queclink Wireless Solutions Co., Ltd. 2019**

## Contents

0. Revision History .....	1
1. Overview .....	3
1.1. Scope .....	3
1.2. Terms and Abbreviations .....	3
2. System Architecture .....	4
3. Message Description .....	5
3.1. Message Format .....	5
3.2. Command and Acknowledgement .....	6
3.2.1. Server Connection .....	6
3.2.1.1. Bearer Setting Information .....	6
3.2.1.2. Backend Server Registration Information .....	8
3.2.1.3. Quick Start Setting .....	11
3.2.2. Device Configuration .....	12
3.2.2.1. Global Configuration .....	12
3.2.2.2. Auto Unlock PIN .....	15
3.2.2.3. Software Protocol Watchdog .....	16
3.2.2.4. Time Adjustment .....	18
3.2.2.5. Non-movement Detection .....	19
3.2.2.6. Function Key Setting .....	21
3.2.2.7. Network Select .....	23
3.2.2.8. Outside Working Hours .....	24
3.2.3. Position Related Report .....	26
3.2.3.1. Fixed Report Information .....	26
3.2.4. Alarm Settings .....	29
3.2.4.1. Geo-Fence Information .....	29
3.2.4.2. Speed Alarm .....	31
3.2.4.3. Temperature Alarm .....	32
3.2.5. IO Application .....	34
3.2.5.1. Digital Input Port Settings .....	34
3.2.6. Other Settings .....	35
3.2.6.1. Real Time Operation .....	35
3.2.6.2. Data Transfer Between UART and Backend Server .....	37
3.2.6.3. White Number List Configuration .....	38
3.2.6.4. Settings for SMS with Google Maps Link .....	40
3.2.6.5. Over-the-Air Configuration Update .....	41
3.2.6.6. Preserve Device Special Logical State .....	43
3.2.6.7. GPS-Assisted Motion Measurement .....	44
3.2.6.8. Command String Storage .....	45
3.2.6.9. User Defined Function .....	46
3.2.6.10. SMS Position Request .....	50
3.3. Report .....	50
3.3.1. Position Related Report .....	50
3.3.1.1. General Position Report .....	50

3.3.1.2. Location Request Report.....	56
3.3.1.3. Location as Centre of Geo-Fence .....	56
3.3.2. Device Information Report .....	57
3.3.3. Report for Querying.....	59
3.3.4. Event Report .....	72
3.3.5. Buffer Report .....	81
3.3.6. Report with Google Maps Hyperlink .....	82
3.4. Heartbeat .....	83
3.5. Sever Acknowledgement.....	83
4. Appendix: Message Index .....	85

Queclink  
Confidential

## 0. Revision History

Version	Date	Author	Description of Change
1.01	2017-08-31	David Liu	Initial
1.02	2017-10-24	David Liu	1. Deleted AGPS and GSV, GTBCS, GTBDS, AT+GTBTC
1.03	2018-01-16	Roger Luo	1. Modified the protocol version number.
1.04	2018-02-27	Parker Xu	1. Added Device Status field in FRI/ERI Report
	2018-03-19	Parker Xu	2. Modified RESP: GTFRI/GTERI Report type
1.05	2018-03-21	Parker Xu	1. Modified Report type field in FRI/ERI Report
1.06	2018-03-23	Parker Xu	1. Added GTGAM
2.01	2018-05-30	Flame Zheng	<ol style="list-style-type: none"> <li>Added &lt;LET Mode&gt; in AT+GTBSI.</li> <li>Modified the &lt;Network Mode&gt; in the AT+GTBSI.</li> <li>Added +RESP:GTLOC</li> <li>Added '4.location mode' and '5.Mixed mode' of the &lt;Function Key Mode&gt; in the AT+GTFKS.</li> <li>Added the &lt;First Trigger time&gt;, &lt;Second Trigger Time&gt;, &lt;First Trigger Event&gt;, &lt;Second Trigger Event&gt; in AT+GTFKS.</li> <li>Modified the &lt;Network Type&gt; in the +RESP:GTAIF.</li> </ol>
3.01	2018-8-06	Flame Zheng	<ol style="list-style-type: none"> <li>Added &lt;AGPS Mode&gt; in the AT+GTCTFG to support GL300M 1713 Series.</li> <li>Corrected the description of some fields in the configuration of GTCTFG and GTOWH.</li> </ol>
3.02	2018-8-29	Flame Zheng	1. Added GTLWM
3.03	2018-9-10	Flame Zheng	1. Added the query command of the GTLWM in the GTRTO
3.04	2018-9-13	Flame Zheng	1. Added the configuration of the APN authentication methods in the GTCTFG
3.05	2018-9-28	Flame Zheng	<ol style="list-style-type: none"> <li>Deleted GTLWM</li> <li>Added the temp and the motion status in the +RESP:GTRTL report.</li> </ol>
3.06	2018-12-18	Kerwin Shen	1. Modify the range of <Hour Offset> in AT+GTTMA command.
5.01	2019-01-07	Flame Zheng	<ol style="list-style-type: none"> <li>Modified the default value of &lt;mode&gt;,&lt;Interval&gt; in the AT+GTDOG.</li> <li>Modified the description of the temp sensor in GTERI report.</li> <li>Added the description of the buff report.</li> <li>Modified the range of &lt;Network Type&gt; in the +RESP:GTAIF.</li> </ol>

6.01	2019-08-08	Flame Zheng	<ol style="list-style-type: none"><li>1. Modify the system architecture.</li><li>2. Modified the AT+GTPDS.</li><li>3. Modified the AT+GTBSI.</li><li>4. Added the note in &lt;Enable ODO&gt; of AT+GTCFG.</li></ol>
7.01	2019-09-16	Flame Zheng	<ol style="list-style-type: none"><li>1. Added the “UDP with fixed local port mode” and “Backup server supported TCP long-connection mode” in &lt;Report Mode&gt; of AT+GTSRI.</li><li>2. Added “GSV” in &lt;Sub Command&gt; of AT+GTRTO.</li><li>3. Added +RESP:GTGSV report.</li></ol>

## 1. Overview

### 1.1. Scope

The @Track Air Interface Protocol, a digital communication interface based on printable ASCII characters over SMS or wireless work, is used for all communications between the backend server and the terminal. The backend server sends a command to the terminal and then the terminal confirms with an acknowledgement message. If configured, the terminal also sends messages to the backend server.

The purpose of this document is to describe how to build the backend server based on the @Track Air Interface Protocol.

### 1.2. Terms and Abbreviations

Table 1: Terms and Abbreviations

Abbreviation	Description
APN	Access Point Name
ASCII	American National Standard Code for Information Interchange
LTE	Long Term Evolution
HDOP	Horizontal Dilution of Precision
ICCID	Integrated Circuit Card Identity
IP	Internet Protocol
SMS	Short Message Service
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
UTC	Coordinated Universal Time

## 2. System Architecture




Figure 1: System Architecture

The backend server needs to be accessible by multiple terminals and should have the following abilities:

- ✧ The backend server should be able to access the internet and listen for the connection requests originating from the terminals.
- ✧ The backend server should be able to support TCP or UDP connection with the terminal. It should be able to receive data from the terminal and send data to the terminal.
- ✧ The backend server should be able to receive and send SMS.

### 3. Message Description

#### 3.1. Message Format

All the @Track Air Interface Protocol messages are composed of printable ASCII characters. Message formats are shown in the table below:

Message Format	Message Type
AT+GTXXX=<parameter1>,<parameter2>,... \$	Command
+ACK:GTXXX, <parameter1>,<parameter2>,... \$	Acknowledgement
+RESP:GTXXX,<parameter1>,<parameter2>,...\$	Report

The entire message string ends with the character '\$'.

The characters 'XXX' allow the identification of the difference between messages.

The "<parameter1>,<parameter2>,..." carries the message's parameters. The number of parameters is different in different messages. The ASCII character "," is used to separate the neighbouring parameter characters. The parameter string may contain the following ASCII characters: '0'-'9', 'a'-'z', and 'A'-'Z'.

Detailed descriptions of each message format are available in the corresponding message sections.

By sending Commands to the terminal, the backend server can either configure and query the parameters of the terminal or control the terminal to perform specific actions. When the terminal receives Commands over the air, it will reply with a corresponding Acknowledgement message.

The device can send other Reports to the server by configuring related parameters. Please see the following figure:




Figure 2: @Track Protocol Message Flow

When the device receives commands over the air, it supports several commands in one SMS or network packet without separation symbol between adjacent commands. Make sure the total size of the several commands is no longer than 160 bytes if the commands are sent via SMS. Here is an example of sending three commands in one SMS.

```
AT+GTFRI=gl300,1,1,,,0000,2359,60,60,,,1F,0,,,,,,,,,0007$AT+GTGEO=gl300,0,3,101.412248,21.18
7891,1000,600,,,,,,,,,0008$AT+GTSPD=gl300,1,5,40,30,60,,,,,,,,,,,,,0009$
```

There are three commands (**AT+GTFRI**, **AT+GTGEO** and **AT+GTSPD**) in the message above. And the terminal will handle the three commands one by one and it will report the following three acknowledgement messages to the backend server one by one.

```
+ACK:GTFRI,F50104,352948070074301,,0007,20161005074622,11F0$
```

```
+ACK:GTGEO,F50104,352948070074301,,0,0008,20161005074623,11F1$
```

```
+ACK:GTSPD,F50104,352948070074301,,0009,20161005074624,11F2$
```

## 3.2. Command and Acknowledgement

### 3.2.1. Server Connection

#### 3.2.1.1. Bearer Setting Information

The command **AT+GTBSI** is used to set the network parameters.

##### ➤ AT+GTBSI=

Example:				
AT+GTBSI=gl300m,,,,,,,,,0002\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	LTE APN	<=40		
3	LTE APN User Name	<=30		
4	LTE APN Password	<=30		
5	GPRS APN	<=40		
6	GPRS APN User Name	<=30		
7	GPRS APN Password	<=30		
8	Network Mode	1	0 - 2	
9	LTE Mode	1	0 - 3	
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

✧ <Password>: The valid characters for the password include '0'-'9', 'a'-'z', and 'A'-'Z'. The

default value is "gl300m".

- ✧ <LTE APN>: The LTE access point name (APN).
  - ✧ <LTE APN User Name>: The LTE APN user name. If the parameter field is empty, the current value of this parameter will be cleared.
  - ✧ <LTE APN Password>: The LTE APN password. If the parameter field is empty, the current value of this parameter will be cleared.
  - ✧ <GPRS APN>: The GPRS access point name (APN). When using a GPRS network, the <GPRS APN> will be used.
  - ✧ <GPRS APN User Name>: The GPRS APN user name. If the parameter field is empty, the current value of this parameter will be cleared.
  - ✧ <GPRS APN Password>: The GPRS APN password. If the parameter field is empty, the current value of this parameter will be cleared.
  - ✧ <Network Mode>: Mobile network modes of the device.
    - 0: Auto. (LTE & GSM)
    - 1: GSM only.
    - 2: LTE only.
  - ✧ <LTE Mode>: Select LTE network mode.
    - 0: Cat-M1 & Cat-NB1. (Cat-M1 First)
    - 1: Cat-NB1 & Cat-M1. (Cat-NB1 First)
    - 2: Cat-M1.
    - 3: Cat-NB1.
- Note:** When <Network Mode> is 1, <LTE Mode> is invalid.
- ✧ <Serial Number>: The serial number of the command. It will be included in the ACK message of the command.
  - ✧ <Tail Character>: A character which indicates the end of the command. And it must be '\$'.

**Note:** If there is only one APN, please use it as LTE APN.

The acknowledgement message of the **AT+GTBSI** command:

➤ **+ACK:GTBSI,**

<b>Example:</b>			
<b>+ACK:GTBSI,F50601,015181001707687,,0040,20190906065404,004F\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Protocol Version>: The protocol version that the terminal conforms to. The first two characters represent the device type. As shown in the example, "F5" means GL300M. The middle two characters represent the major version number of the protocol and the last two characters represent the minor version number of the protocol. And all the version numbers

are hex digits. For example, “0101” means version 1.01.

- ✧ <Unique ID>: The (IMEI) of the terminal.
- ✧ <Device Name>: The specified name of the device.
- ✧ <Serial Number>: A serial number which is included in the corresponding command and is used to distinguish which command the ACK message is for.
- ✧ <Send Time>: The local time to send the ACK message.
- ✧ <Count Number>: A self-increasing count number in each acknowledgment message and other messages. It begins from “0000” and increases by 1 for each message. And it rolls back after “FFFF”.
- ✧ <Tail Character>: A character which indicates the end of the command. It must be ‘\$’.

**Note:** Only after both the commands **AT+GTBSI** and **AT+GTSRI** are properly set can the ACK messages and other messages be received by the backend server.

### 3.2.1.2. Backend Server Registration Information

The command **AT+GTSRI** is used to configure the backend server that the terminal reports to and the report mode that defines the communication method between the backend server and the terminal.

#### ➤ AT+GTSRI=

Example:				
AT+GTSRI=gl300m,3,,1,218.17.46.11,95,213.175.74.200,5682,13824347475,5,1,1,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Report Mode	1	0 - 7	0
3	Reserved	0		
4	Buffer Mode	1	0 1 2	1
5	Main Server IP/Domain Name	<=60		
6	Main Server Port	<=5	0 - 65535	0
7	Backup Server IP/Domain Name	<=60		
8	Backup Server Port	<=5	0 - 65535	0
9	SMS Gateway	<=20		
10	Heartbeat Interval	<=3	0 5 - 360(min)	0
11	SACK Enable	1	0 1 2	0
12	SMS ACK Enable	1	0 1	0
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		

16	Serial Number	4	(HEX)	
17	Tail Character	1	\$	\$

✧ *<Report Mode>*: Supported report modes are as follows:

- 0: Stop mode.
- 1: TCP short-connection preferred mode. The connection is based on TCP protocol. The terminal connects to the backend server every time it needs to send data and will cut off the connection when the terminal finishes sending data. And if the terminal fails to establish TCP connection with the backend server (including main server and backup server), it will try to send data via SMS.
- 2: TCP short-connection forced mode. The connection is based on TCP protocol. The terminal connects to the backend server every time it needs to send data and will cut off the connection when the terminal finishes sending data. And if the terminal fails to establish TCP connection with the backend server (including main server and backup server), the data will be stored in the BUFFER (if BUFFER function is enabled, please refer to *<Enable Buffer>*) or discarded (if the BUFFER function is disabled).
- 3: TCP long-connection mode. The connection is based on TCP protocol. The terminal connects to the backend server and maintains the connection by using the heartbeat data. Please note that in this mode the backend server should respond to the heartbeat data from the terminal.
- 4: UDP mode. The terminal will send data to the backend server through the UDP protocol. It supports receiving protocol command via UDP. Make sure the IP address and UDP port of the device can be visited over the internet, which is generally realized by heartbeat package and the message **+RESP:GTPDP**.
- 5: Force on SMS mode. Only SMS is used for data transmission.
- 6: UDP with fixed local port mode. Like the UDP mode, the terminal will send data by using UDP protocol. The difference is the terminal will use a fixed local port rather than a random port to communicate with the server in this mode. Thus the backend server could use the identical port to communicate with all terminals if the backend server and the terminals are all in the same VPN network. The port number the device uses is the same as the port number of the main server.
- 7: Backup server supported TCP long-connection mode. The connection is based on TCP protocol. The terminal connects to the backend server and maintains the connection by using the heartbeat data. The backend server should respond to the heartbeat data from the terminals. If the main server is lost, it will try to connect the backup server. And if the backup server is also lost, it will try to connect the main server again.

✧ *<Reserved>*: Not used at present. Please keep it empty.

✧ *<Buffer Mode>*: Enable or disable the BUFFER function. Please refer to Chapter 3.3.5 for details of the BUFFER function.

- 0: Disable the BUFFER function.
- 1: Enable the BUFFER function.
- 2: High priority—Enable the buffer report function. Under this working mode, the device will send all the buffered messages before sending real-time messages except

the SOS message (**+RESP:GTSOS**).

- ✧ <Main Server IP/Domain Name>: The IP address or the domain name of the main server.
- ✧ <Main Server Port>: The port of the main server.
- ✧ <Backup Server IP>: The IP address of the backup backend server.
- ✧ <Backup Server Port>: The port of the backup server.
- ✧ <SMS Gateway>: Maximum 20 characters (including the optional national code starting with "+"). Short code (for example, 10086) is also supported.
- ✧ <Heartbeat Interval>: The interval for the terminal to send the heartbeat message to the backend server. If it is set to 0, no heartbeat message will be sent.
- ✧ <SACK Enable>: A numeral to indicate whether the backend server should reply with a SACK message to the device.
  - 0: The backend server does not reply with a SACK message after receiving a message from the device.
  - 1: The backend server should reply with a SACK message after receiving a message from the device.
  - 2: The backend server replies with a SACK message when receiving a message from the terminal, but the terminal does not check the serial number of the SACK message.
- ✧ <SMS ACK Enable>: This defines whether the ACK confirmation should be replied via SMS when the command is sent via SMS.
  - 0: The device will send the ACK confirmation according to the configuration of <Report Mode>.
  - 1: The device will send the ACK confirmation via SMS to the phone which sends the command by SMS.
- ✧ <Reserved>: Not used at present. Please keep it empty.
- ✧ <Serial Number>: The serial number of the command. It will be included in the ACK message of the command.
- ✧ <Tail Character>: A character to indicate the end of the command. And it must be '\$'.

**Note:** If <Report Mode> is set to 4 (UDP mode), it is recommended to enable SACK or heartbeat mechanism (in this case, <Heartbeat Interval> should not be set to 0). Otherwise the backend server may not be able to send commands to the terminal.

The acknowledgement message of the **AT+GTSRI** command:

➤ **+ACK:GTSRI,**

Example:			
<b>+ACK:GTSRI,F50601,015181001707687,,0044,20190906070335,005C\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	

Tail Character	1	\$	\$
----------------	---	----	----

**Note:** Only after both the commands **AT+GTBSI** and **AT+GTSRI** are properly set can the ACK messages and other messages be received by the backend server.

### 3.2.1.3. Quick Start Setting

The command **AT+GTQSS** is used to set the network parameters and backend server information if the length of all its settings is within 160 bytes. Otherwise, use two commands **AT+GTBSI** and **AT+GTSRI** to configure the settings.

#### ➤ **AT+GTQSS=**

Example:				
<b>AT+GTQSS=gl300m,net,,,3,,1,218.17.46.11,91,213.175.74.200,5682,13824347475,0,0,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '-'	gl300m
2	LTE APN	<=40		
3	LTE APN User Name	<=30		
4	LTE APN Password	<=30		
5	Report Mode	1	0 - 7	0
6	Reserved	0		
7	Buffer Mode	1	0 1 2	1
8	Main Server IP/Domain Name	<=60		
9	Main Server Port	<=5	0 - 65535	0
10	Backup Server IP/Domain Name	<=60		
11	Backup Server Port	<=5	0 - 65535	0
12	SMS Gateway	<=20		
13	Heartbeat Interval	<=3	0 5 - 360(min)	0
14	SACK Enable	1	0 1 2	0
15	Reserved	0		
16	Reserved	0		
17	Serial Number	4	(HEX)	
18	Tail Character	1	\$	\$

The acknowledgement message of the **AT+GTQSS** command:

#### ➤ **+ACK:GTQSS,**

Example:			
<b>+ACK:GTQSS,F50601,015181001707687,,0045,20190906070824,0062\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	

Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2. Device Configuration

#### 3.2.2.1. Global Configuration

The **AT+GTCFG** command is used to configure the global parameters.

##### ➤ AT+GTCFG=

**Example:**  
**AT+GTCFG=gl300m,gl300m,GL300M,0,0.0,1,5,1F,0,,3FFF,0,1,0,300,2,0,20491231235959,0,,1,FF**  
**FF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	New Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	
3	Device Name	20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
4	Enable ODO	1	0 1	0
5	ODO Initial Mileage	<=9	0.0 - 4294967.0(km)	0.0
6	GPS On Need	1	0 1 2	1
7	GPS Fix Delay	2	5 - 60(sec)	5
8	Report Item Mask	<=4	0000 - 007F	001F
9	APN Authentication Methods	1	0 - 3	0
10	Reserved	0		
11	Event Mask	4	0000 - 3FFF	0FFF
12	EPB mode	1	0 1	0
13	LED On	1	0 - 2	1
14	Info Report Enable	1	0 1	1
15	Info Report Interval	<=5	30 - 86400(sec)	300
16	Location Request Mask	1	0 2	2
17	Expiry Enable	1	0 1	0
18	Expiry Time	14	YYYYMMDDHHMMSS	204912312 35959
19	AGPS Mode	1	0 1	0

20	Reserved	0		
21	Battery Switch Power On	1	0 1	0
22	Serial Number	4	(HEX)	
23	Tail Character	1	\$	\$

- ✧ <New Password>: It is used to change the current password.
- ✧ <Device Name>: The name of the device. It appears in each message.
- ✧ <Enable ODO>: Enable or disable the odograph function to calculate the total mileage. The current mileage is included in the message **+RESP:GTINF**.
  - 0: Disable the ODO mileage function.
  - 1: Enable the ODO mileage function.

**Note:** The device will calculate the mileage even if <GPS on Need> is set to 1: Turn off GPS chip after retrieving GPS information every time. But the mileage will be calculated by using the last fix point before turning off GPS and current fix point. So the calculation will not be as accurate as keeping the GPS always on.
- ✧ <ODO Initial Mileage>: The value of current total mileage.
- ✧ <GPS on Need>: Whether to turn off GPS chip after retrieving GPS position information.
  - 0: Do not turn off GPS chip.
  - 1: Turn off GPS chip after retrieving GPS information every time.
  - 2: Do not turn off GPS chip in ignition on state or movement state.
- ✧ <GPS Fix Delay>: This value indicates the waiting time after GPS fix succeeds. After GPS fix succeeds, the device will wait for a period of time (specified by <GPS Fix Delay>) and then get the result of GPS fix because the position obtained immediately after the GPS fix may not be accurate. (e.g. If <GPS Fix Delay> is set to 7, the device will wait 7 seconds after GPS fix and then get the fix result). The range of the parameter value is 5 - 60, and the default value is 5. Unit: second.
- ✧ <Report Item Mask>: Bitwise report mask to configure the composition of all the report messages. Each bit represents a field in the message. If a bit is set to 1, the corresponding field will be filled if it is included in the message. Otherwise, the field will be empty.
  - Bit 0 (0001): <Speed>
  - Bit 1 (0002): <Azimuth>
  - Bit 2 (0004): <Altitude>
  - Bit 3 (0008): Cell information, including <MCC>, <MNC>, <LAC>, and <Cell ID>
  - Bit 4 (0010): <Send Time>
  - Bit 5 (0020): <Device Name>
  - Bit 6 (0040): Reserved
- ✧ <APN Authentication Methods>: Configure the APN authentication methods.
  - 0: NO one
  - 1: PAP authentication
  - 2: CHAP authentication
  - 3: PAP or CHAP authentication
- ✧ <Event Mask>: A Hex value to configure which event reports can be sent to the backend server. Each bit corresponds to a message. If the bit is set to 1, the corresponding message can be sent to the backend server. Otherwise, the corresponding message cannot be sent to

the backend server. Here is the matching between each bit and message.

- Bit 0 (0001): **+RESP:GTPNA**
- Bit 1 (0002): **+RESP:GTPFA**
- Bit 2 (0004): **+RESP:GTEPN**
- Bit 3 (0008): **+RESP:GTEPF**
- Bit 4 (0010): Reserved
- Bit 5 (0020): **+RESP:GTBPL**
- Bit 6 (0040): **+RESP:GTBTC**
- Bit 7 (0080): **+RESP:GTSTC**
- Bit 8 (0100): **+RESP:GTSTT**
- Bit 9 (0200): Reserved
- Bit 10 (0400): **+RESP:GTPDP**
- Bit 11 (0800): **+RESP:GTPNL**
- Bit 12 (1000): **+RESP:GTIGN** and **+RESP:GTIGF**
- Bit 13 (2000): **+RESP:GTIGL**

- ✧ **<EPB Mode>**: The mode of External Power Control Unit with Built-in Motion Sensor.
  - 0: Disable External Power Control Unit with Built-in Motion Sensor.
  - 1: Enable External Power Control Unit with Built-in Motion Sensor.
- ✧ **<LED On>**: It configures the working mode of LEDs.
  - 0: Each time after the device powers on or the parameter is set to 0, GPS LED will work for 150 seconds and then shut off. NET LED and Power LED work normally.
  - 1: All LEDs work normally.
  - 2: All LEDs are off except the following circumstances: a. All LEDs work for a period time after power on. b. Power LED flashes fast during power off process. c. Power LED works normally in charging status when a charger is inserted in power off state.
- ✧ **<Enable Info Report>**: Enable/disable the device information report (**+RESP:GTINF**) function. The device information includes state of the device, ICCID, network signal strength, adapter connection status, battery voltage, charging status, Power and GPS LED working mode, GPS on need setting, GPS antenna type, GPS antenna status, and the time of last known GPS fix.
  - 0: Disable the device information report function.
  - 1: Enable the device information report function.
- ✧ **<Info Report Interval>**: The interval for reporting the device information.
- ✧ **<Location Request Mask>**: Mask to control the location request
  - Bit 0: Reserved.
  - Bit 1: SMS Location Request.
- ✧ **<Enable Expiry>**: Enable or disable the expiry function to stop all the GPS fixing and reports.
  - 0: Disable the Expiry function.
  - 1: Enable the Expiry function.
- ✧ **<Expiration Time>**: The time to stop all the GPS fixing and reports. The valid format is "YYYYMMDDHHMMSS". The value range of "YYYY" is "2000"- "3000". The value range of "MM" is "01"- "12". The value range of "DD" is "00"- "31". The value range of "HH" is "00"- "23". The value range of "MM" is "00"- "59". The value range of "SS" is "00"- "59". Please note that RTC time is used here.
- ✧ **<AGPS Mode>**: A numeral to indicate whether to enable AGPS. AGPS helps increase the

chances of getting GPS position successfully and reduces the time needed to get GPS position.

- 0: Disable the AGPS function.
- 1: Enable the AGPS function.

✧ <Battery Switch Power On>: A numeral to indicate whether the device will reboot after the external battery is removed.

- 0: The device will power off.
- 1: The device will switch to internal battery and reboot.

**Note:** <AGPS Mode> is only supported by GL300M 1713 Series.

The acknowledgement message of the **AT+GTCFG** command:

➤ **+ACK:GTCFG,**

Example:			
<b>+ACK:GTCFG,F50601,015181001707687,,0047,20190906071107,0067\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.2. Auto Unlock PIN

The **AT+GTPIN** command is used to unlock the USIM automatically.

➤ **AT+GTPIN=**

Example:				
<b>AT+GTPIN=gl300m,1,1234,1,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Auto Unlock PIN	1	0 1	1
3	PIN	4- 8	'0' - '9'	
4	PIN Check	1	0 1	0
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Serial Number	4	(HEX)	
10	Tail Character	1	\$	\$

- ✧ <Auto Unlock PIN>: A numeral to indicate whether to unlock the USIM-PIN for the device.
  - 0: Do not unlock USIM-PIN automatically.
  - 1: Each time the device powers on, it will detect whether the USIM card is locked with a PIN. If it is locked, the device will auto-unlock the PIN.
- ✧ <PIN>: The PIN code which is used for unlocking PIN automatically. If it is empty, the PIN code saved in the device will be cleared.
- ✧ <PIN Check>: A numeral to indicate whether to lock the device with USIM-PIN.
  - 0: Do not lock the USIM-PIN.
  - 1: Lock the USIM-PIN.

The acknowledgment message of the **AT+GTPIN** command:

➤ **+ACK:GTPIN,**

Example:			
<b>+ACK:GTPIN,F50601,015181001707687,,0048,20190906071252,0068\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.3. Software Protocol Watchdog

The **AT+GTD0G** command is used to reboot the device in a time based manner or upon ignition. This helps the device avoid working in an abnormal status for a long time. Besides these two automatic reboot methods, the device also supports the use of the digital input to trigger the reboot manually.

➤ **AT+GTD0G=**

Example:				
<b>AT+GTD0G=gl300m,1,60,7,0200,,1,0,0,480,480,480,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Mode	1	0 1 2	1
3	Ignition Frequency	<=3	10 - 120	60
4	Reboot Interval	<=2	1 - 30	7
5	Reboot Time	4	HHMM	0200
6	Reserved	0		
7	Report Before Reboot	1	0 1	1

8	Input ID	1	0 1	0
9	Unit	1	0 1	0
10	No Network Interval	4	0 5 - 1440(min)	480(min)
11	No Activation Interval	4	0 5 - 1440(min)	480(min)
12	Send Fail Timeout	4	0 5 - 1440(min)	480(min)
13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

- ✧ **<Mode>**: The working mode of the watchdog function.
  - 0: Disable this function.
  - 1: Reboot periodically according to the **<Interval>** and **<Time>** settings.
  - 2: Reboot when the ignition is turned on.
- ✧ **<Ignition Frequency>**: If the time interval between two ignitions is greater than the specified value when the working mode is 2, the device will automatically reboot upon ignition on. If the function is enabled for the first time, the device will reboot at next ignition even if the interval is less than the value set in Ignition Frequency.
- ✧ **<Reboot Interval>**: The interval for rebooting the device.
- ✧ **<Reboot Time>**: The time to perform the reboot operation when the **<Interval>** is met.
- ✧ **<Report Before Reboot>**: Whether to report the **+RESP:GTDOG** message before reboot. 0 means "Do not report the **+RESP:GTDOG** message before reboot", and 1 means "Report the **+RESP:GTDOG** message before reboot". If this parameter is enabled, the device will obtain a real-time location and send it to the server.
- ✧ **<Input ID>**: The ID of the digital input port which is used to trigger the reboot manually. 0 means "Do not use manual reboot". Only port 1 is supported.
- ✧ **<Unit>**: The unit of the **<Interval>** value.
  - 0: Day.
  - 1: Hour.
- ✧ **<No Network Interval>**: The interval for rebooting the device in no network signal situation. 0 means "Do not reboot the device".
- ✧ **<No Activation Interval>**: The interval for rebooting the device when PDP context activation fails or the interaction of messages fails (e.g. no TCP ACK or Server ACK). 0 means "Do not reboot the device".
- ✧ **<Send Fail Timeout>**: The time (minute) before rebooting the device when the device cannot send a message successfully. 0 means no rebooting the device.

The acknowledgment message of the **AT+GTDOG** command:

➤ **+ACK:GTDOG,**

Example:			
<b>+ACK:GTDOG,F50601,015181001707687,,0049,20190906071358,0069\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		

Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.4. Time Adjustment

The command **AT+GTTMA** is used to adjust local time.

#### ➤ AT+GTTMA=

Example:				
AT+GTTMA=gl300m,+0,0,0,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
2	Sign	1	+/-	+
3	Hour Offset	<=2	0 - 12	00
4	Minute Offset	<=2	0 - 59	00
5	Daylight Saving	1	0 1	0
6	UTC Time	14	YYYYMMDDHHMMSS	
7	Reserved			
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Serial Number	4	(HEX)	
12	Tail Character	1	\$	\$

- ✧ <Sign>: It indicates the positive or negative offset of the local time from UTC time.
- ✧ <Hour Offset>: The UTC offset in hours.
- ✧ <Minute Offset>: The UTC offset in minutes.
- ✧ <Daylight Saving>: Enable/disable daylight saving time.
  - 0: Disable daylight saving time.
  - 1: Enable daylight saving time.
- ✧ <UTC Time>: UTC time used to adjust the local time.

The acknowledgement message of the **AT+GTTMA** command:

#### ➤ +ACK:GTTMA,

Example:			
+ACK:GTTMA,F50601,015181001707687,,004A,20190906071451,006A\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	

Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.5. Non-movement Detection

The **AT+GTNMD** command is used to configure the parameters for non-movement detection.

#### ➤ AT+GTNMD=

Example: AT+GTNMD=gl300m,0,2,3,2,300,300,2,3,0,0,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
2	Mode	1	0 - F	0
3	Non-movement Duration	<=3	1 - 255 (*14sec)	2
4	Movement Duration	<=2	1 - 50 (*128ms)	3
5	Movement Threshold	1	2 - 9	2
6	Fix Interval at Rest	5	5 - 86400(sec)	300
7	Send Interval at Rest	5	5 - 86400(sec)	300
8	PM Rest Threshold	1	2 - 9	2
9	PM Motion Threshold	1	2 - 9	3
10	URC Report	1	0 1	0
11	Enter Movement by Command	1	0 1	0
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Serial Number	4	(HEX)	
16	Tail Character	1	\$	\$

✧ **<Mode>**: A hex numeral to determine how the function works. Each bit of the hex numeral indicates different actions the device can perform. If a bit is 1, the device will perform the corresponding action as described below.

Bit 0 (1): Suspend the report of FRI and Geo-fence when it detects non-movement.

Bit 1 (2): Report the message **+RESP:GTNMR** to the backend server when it detects non-movement.

Bit 2 (4): Report the message **+RESP:GTNMR** to the backend server when it detects movement.

Bit 3 (8): Change the fix interval and send interval of FRI to *<Rest Fix Interval>* and

- <Rest Send Interval> when it detects non-movement. In this case, it just modifies the fix interval and send interval of FRI but does not suspend the report of FRI even if Bit 0 is 1.
- ✧ <Non-movement Duration>: A time parameter to determine whether the device enters non-movement status. If the motion sensor detects that the device stays in non-movement status for a period of time specified by <Non-movement Duration>, the device will be considered to be in non-movement status.
  - ✧ <Movement Duration>: A time parameter to determine whether the device enters movement status. If the motion sensor detects that the device stays in movement for a period of time specified by <Movement Duration>, the device will be considered to be in movement status.
  - ✧ <Movement Threshold>: The threshold for the motion sensor to determine whether the device is in movement state. The smaller the value is, the easier it will be for the device to be considered to enter the state of movement.
  - ✧ <Fix Interval at Rest>: The fix interval for the report of FRI when the device is in rest state and Bit 3 of <Mode> is 1.
  - ✧ <Send Interval at Rest>: The send interval for the report of FRI when the device is in rest state and Bit 3 of <Mode> is 1.
  - ✧ <PM Rest Threshold>: The threshold for the EBK motion sensor to determine whether the EBK enters non-movement state.
  - ✧ <PM Motion Threshold>: The threshold for the EBK motion sensor to determine whether the EBK enters movement state.
  - ✧ <URC Report>: Enable or disable outputting sensor state through URC.
    - 0: Do not output the sensor's state to UART.
    - 1: Output a URC to UART to indicate the state change. "SENSOR:REST" means "State changing from MOTION to REST". "SENSOR:MOTION" means "State changing from REST to MOTION".
  - ✧ <Enter Movement by Command>: A numeral to indicate whether to force the device to enter movement state after receiving the **AT+GTRTO** command with subcommand **RTL** or getting state update in **AT+GTLW** from EBK.
    - 0: Do not change motion state after receiving the commands.
    - 1: Force the device to enter movement state after receiving one of the commands.

The acknowledgement message of the **AT+GTNMD** command:

➤ **+ACK:GTNMD,**

Example:			
<b>+ACK:GTNMD,F50601,015181001707687,,004B,20190906071610,006B\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.6. Function Key Setting

The **AT+GTFKS** command is used to configure the functions of the power key and the function key.

➤ **AT+GTFKS=**

Example:				
AT+GTFKS=gl300m,0,1,0,0,0,3,3,4,4,3,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Power Key Mode	1	0 1 2	1
3	Full Power On	1	0 1	1
4	Function Key Mode	1	0 1 2 3 4 5	3
5	Power Key Indication	0	0 1	0
6	Function Key Indication	0	0 1	0
7	SOS Report Mode	1	1 2 3	3
8	First Trigger Time	<=2	1 - 99s	3
9	Second Trigger Time	<=2	1 - 99s	4
10	First Trigger Event	1	0 - 4	4
11	Second Trigger Event	1	0 - 4	3
12	Serial Number	4	(HEX)	
13	Tail Character	1	\$	\$

- ✧ **<Power Key Mode>**: A numeral to indicate the working mode of the power key.
  - 0: Pressing power key will not power off the device.
  - 1: Pressing power key will power off the device.
  - 2: Long pressing power key to activate the SOS mode.
- ✧ **<Full Power On>**: A numeral to indicate whether the terminal powers on completely after charger is inserted.
  - 0: Do not power on the terminal completely. And the terminal will only be charged.
  - 1: Power on the terminal completely. The terminal will work as normally as it is powered on by long pressing the power key.
- ✧ **<Function Key Mode>**: The working mode for the function key operation.
  - 0: Ignore the function key operation.
  - 1: Geo-fence mode. Enable/disable the Geo-fence ID 0 when the function key is long pressed. After the function key is long pressed, the terminal will report the message **+RESP:GTSWG** to inform whether to enable or disable Geo-Fence ID 0 .
  - 2: Geo-fence around the current position. Enable/disable the Geo-fence ID 0 when the function key is long pressed and use the current position as the center of Geo-fence ID 0. After the function key is long pressed, the terminal will report the message **+RESP:GTSWG** immediately. If this operation is expected to enable Geo-fence ID 0, the terminal will start GPS fixing to get the current position as the center of Geo-fence ID 0. After GPS fixing finishes, the terminal will report the

- message **+RESP:GTGCR** to indicate the GPS fix result and whether Geo-fence ID 0 has been enabled successfully.
- 3: SOS mode. When the function key is long pressed, the device will report the current position according to the result of the latest GPS fix and then start GPS fixing. After the GPS fixing finishes or timeout expires, the device will report the SOS message according to the GPS fix result.
  - 4: Location mode. After long press, the device will report a location report "**+RESP:GTLOC**" to the backend server with the real time position.
  - 5: Mixed mode. The device will report different message defined by *<First Trigger Event>* and *<Second Trigger Event>* after pressing for the time set by *<First Trigger Time>*, or *<Second Trigger Time>*.
- ✧ *<Power Key Indication>*: A numeral to indicate the working mode of the motor for power key operation.
- 0: Disable the motor when the power key is long pressed.
  - 1: Enable the motor to vibrate when the power key is long pressed to power off.
- ✧ *<Function Key Indication>*: A numeral to indicate the working mode of the motor for function key operation.
- 0: Disable the motor when the function key is long pressed.
  - 1: Enable the motor to vibrate when the function key is long pressed.
- ✧ *<SOS Report Mode>*: A numeral to indicate the way of reporting GPS location for SOS event.
- 1: Report only the last GPS location immediately after SOS event is triggered.
  - 2: Try to report the current GPS location after SOS event is triggered.
  - 3: Report the last GPS location immediately after SOS event is triggered and then tries to get the current GPS location to report.
- ✧ *<First Trigger Time>*: For function key's mixed mode, this is a numeric to indicate the time (second) before triggering the first trigger event after the function key is pressed, and if *<Function Key Indication>* is enabled, the motor will vibration once. For function key's other modes, this is a numeric to indicate the long press time (second).
- ✧ *<Second Trigger Time>*: A numeric to indicate the time (second) before triggering the second trigger event after the function key is pressed, this time must be longer than *<First Trigger Time>*, and if *<Function Key Indication>* is enabled, the motor will vibration twice. The parameter is valid only when *<Function Key Mode>* is set to 5 (Mixed mode).
- ✧ *<First Trigger Event>*: Event to trigger after function key is pressed for *<First Trigger Time>* and the *<Function Key Mode>* is set to 5 (Mixed mode).
- 0: Ignore the function key operation
  - 1: Geo-fence mode
  - 2: Geo-fence around current position
  - 3: Send a SOS message to back server
  - 4: Send a **+RESP:GTLOC** to back server
- ✧ *<Second Trigger Event>*: Event to trigger after function key is pressed for *<Second Trigger Time>* and the *<Function Key Mode>* is set to 5 (Mixed mode).
- 0: Ignore the function key operation
  - 1: Geo-fence mode
  - 2: Geo-fence around current position

- 3: Send a SOS message to back server
- 4: Send a **+RESP:GTLOC** to back server

The acknowledgement message of the **AT+GTFKS** command:

➤ **+ACK:GTFKS,**

Example:			
<b>+ACK:GTFKS,F50601,015181001707687,,004C,20190906071635,006C\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.2.7. Network Select

The AT+GTNTS command is used to set network when the signal is weak.

➤ **AT+ GTNTS=**

Example:			
<b>AT+GTNTS=gl300m,0,0,0,,10,,FFFF\$</b>			
Parameter	Length (byte)	Range/Format	Default
Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
enable	1	0 1	0
Rssi threshold	3	0 - 35	30
Interval	3	0 - 300(min)	10
Oper1	10		
Oper2	10		
Oper3	10		
GSM Interval	3	0 - 300(min)	10
Reserved	0		
Serial number	4	(HEX)	
Tail character	1	\$	\$

✧ *<Enable>*: Enable or disable "NTS" based functionality.

- 0: Disable
- 1: Enable

✧ *<Rssi threshold>*: The threshold of the CSQ value.

✧ *<Interval>*: The interval to change to another operator.

✧ *<Oper1>*: The first network to select when it is under threshold over Interval.

✧ *<Oper2>*: The second network to select when it is under threshold over Interval.

- ✧ <Oper3>: The third network to select when it is under threshold over Interval.
- ✧ <GSM Interval>: The time (minute) before changing the operator without GSM network.

The acknowledgment message of AT+ GTNTS command:

➤ **+ACK:GTNTS**

Example:			
<b>+ACK:GTNTS,F50601,015181001707687,,004F,20190906071850,006E\$</b>			
Parameter	Length (byte)	Range/Format	Default
Protocol version	6	(HEX)	
Unique ID	15	(IMEI)	
Device name	20		
Serial number	4	(HEX)	
Send time	14	YYYYMMDDHHMMSS	
Count number	4	(HEX)	
Tail character	1	\$	\$

### 3.2.2.8. Outside Working Hours

To protect the privacy of the drivers when they are off duty, the device can be configured to report empty location information outside working hours. The command **AT+GTOWH** is used to define the working hours and the working mode. When this function is enabled, the device will report empty latitude, empty longitude, empty Cell ID, empty LAC, empty MCC and empty MNC in all the messages except **+RESP:GTSOS**.

➤ **AT+GTOWH=**

Example:				
<b>AT+GTOWH=gl300m,0,0,0900,1200,1300,1800,,,0,0,,,,,,FF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Mode	1	0 1 2 3	0
3	Day of Work	<=2	0 - 7F	1F
4	Working Hours Start1	4	HHMM	0900
5	Working Hours End1	4	HHMM	1200
6	Working Hours Start2	4	HHMM	1300
7	Working Hours End2	4	HHMM	1800
8	Reserved	0		
9	Reserved	0		
10	Digital Input ID	1	0 1	0
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		

14	Reserved	0		
15	Reserved	0		
16	Reserved	0		
17	Reserved	0		
18	Reserved	0		
19	Serial Number	4	(HEX)	
20	Tail Character	1	\$	\$

- ✧ **<Mode>**: The working mode of this function.
  - 0: Disable this function.
  - 1: Manual start mode. In this mode, location information will be hidden under two conditions: the device works at outside the working hours and digital input is triggered.
  - 2: Full manual mode. In this mode, location information will be hidden under the following condition: the digital input is triggered.
  - 3: Automatic mode. In this mode, location information will be hidden under the following condition: the device works at outside the working hours.
- ✧ **<Day of Work>**: It specifies the working days in a week in bitwise manner.
  - Bit 0 for Monday
  - Bit 1 for Tuesday
  - Bit 2 for Wednesday
  - Bit 3 for Thursday
  - Bit 4 for Friday
  - Bit 5 for Saturday
  - Bit 6 for Sunday

For each bit, 0 means “off duty day”, and 1 means “working day”.
- ✧ **<Working Hours Start1>, <Working Hours End1>**: The first period of the working hours in a day.
- ✧ **<Working Hours Start2>, <Working Hours End2>**: The second period of the working hours in a day.
- ✧ **<Digital Input ID>**: The input ID used to trigger this function when the **<Mode>** is 1 or 2. Only digital input port 1 is supported.

The acknowledgment message of the **AT+GTOWH** command:

➤ **+ACK:GTOWH,**

Example:			
<b>+ACK:GTOWH,F50601,015181001707687,,004E,20190906071721,006D\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	
Serial Number	4	(HEX)	

Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.3. Position Related Report

#### 3.2.3.1. Fixed Report Information

The command **AT+GTFRI** is used to configure the parameters for scheduled report.

#### ➤ AT+GTFRI=

Example:				
AT+GTFRI=gl300m,1,0,,,0000,2359,30,30,60,60,,1000,1000,0,3,24,3,60,00000000,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Mode	1	0 1 2 3 4 5 6	0
3	Discard No Fix	1	0 1	1
4	Reserved	0		
5	Reserved	0		
6	Begin Time	4	HHMM	0000
7	End Time	4	HHMM	0000
8	Check Interval	<=5	5 - 86400(sec)	180
9	Send Interval	<=5	5 - 86400(sec)	180
10	Ignition Check Interval	<=5	5 - 86400(sec)	180
11	Ignition Send Interval	<=5	5 - 86400(sec)	180
12	Reserved	0	.	
13	Distance	<=5	50 - 65535m	1000
14	Mileage	<=5	50 - 65535m	1000
15	Movement Detection Mode	1	0 1	0
16	Movement Speed	<=3	1 - 999((km/h))	5
17	Movement Distance	<=4	1 - 9999(m)	50
18	Movement Send Number	1	1 - 5	5
19	Corner	3	0 - 180	0
20	ERI Mask	8	00000000 - FFFFFFFF	00000000
21	Serial Number	4	(HEX)	
22	Tail Character	1	\$	\$

✧ <Mode>: The working mode of the fixed report function.

- 0: Disable the fixed report function.
- 1: Enable the fixed time report.
- 2: Enable the fixed distance report. The device reports its position each time the

- linear distance that the device has moved exceeds the specified distance. It ignores the specific path the device has passed along. This function is valid only when the GPS chip keeps working. Unit: Meter.
- 3: Enable the fixed mileage report. The device reports its position each time the path length that the device has moved exceeds the specified length. It calculates the length of the path the device has passed along. This function is valid only when the GPS chip keeps working. Unit: Meter.
  - 4: Optimum Report. The device simultaneously checks both time interval and path length between two adjacent reports. Device position will be reported if the calculated time interval between the current time and the time of last report is greater than the *<Send Interval>*, and the length of path between the current position and the last position is greater than the *<Mileage>*. In order for the function to work, *<GPS on Need>* must be 0 (Do not turn off GPS chip) or 2 (Do not turn off GPS chip in ignition on state or movement state).
  - 5: Reserved.
  - 6: Fixed Time or Mileage Report. The device checks either time interval or path length between two adjacent position reports. Device position will be reported if the calculated time interval between the current time and the time of last report is greater than the *<Send Interval>*, or the length of path between the current position and the last position is greater than the *<Mileage>*.
- ✧ *<Discard No Fix>*: 0 means "Report last known GPS position if there is no GPS fix", and 1 means "Do not send position information if there is no GPS fix".
  - ✧ *<Begin Time>*: The start time of scheduled report. The valid format is "HHMM". The value range of "HH" is "00"-"23". The value range of "MM" is "00"-"59". Please note that system time is used here.
  - ✧ *<End Time>*: The end time of scheduled report. The valid format and range are the same as those of *<Begin Time>*.
  - ✧ *<Check Interval>*: The time interval for GPS fix when the device attached vehicle is ignition off. Its value range is 5-86400 and the unit is second.
  - ✧ *<Send Interval>*: The interval to send the position information when the device attached vehicle is ignition off. The value range is 5- 86400 and the unit is second.
  - ✧ *<Ignition Check Interval>*: The time interval for GPS fix when the device attached vehicle is ignition on. Its value range is 5-86400 and the unit is second.
  - ✧ *<Ignition Send Interval>*: The time interval for sending the position information when the device attached vehicle is ignition on. The value range is 5-86400 and the unit is second.
  - ✧ *<Distance>*: The specified distance for sending the position information when *<Mode>* is 2 and this parameter is valid only when GPS chip keeps working. Unit: meter.
  - ✧ *<Mileage>*: The specified path length to send the position information when *<Mode>* is 3 and this is valid only when GPS chip keeps working. Unit: meter.
  - ✧ *<Movement Detection Mode>*: Enable or disable the movement detection function.
    - 0: Disable the movement detection function.
    - 1: Enable the movement detection function. The device is considered to be in non-movement state if the speed shown in the GPS fix result is less than *<Movement Speed>* and the distance between the current GPS position and the last GPS position

is less than *<Movement Distance>*. If the device is considered to be in non-movement state, it will report FRI messages (speed field is shown as - 1 in these messages) *<Movement Send Number>* times at most.

- ✧ *<Movement Speed>*: The speed threshold for movement detection. The unit is (km/h).
- ✧ *<Movement Distance>*: The distance threshold for movement detection. The unit is meter.
- ✧ *<Movement Send Number>*: If the terminal is considered to be staying at the same position based on the speed threshold and distance threshold, the terminal will send at most this number of reports before it moves again.
- ✧ *<Corner>*: A numeral to indicate whether to report the **+RESP:GTFRI** message according to the heading change, i.e. the change of the device's movement direction.
  - 0: Disable the function. Do not detect whether the device has changed its direction.
  - 1-180: The angle is used to determine whether the device is turning around. If the heading change is greater than the specified value, the device will be considered to be turning around. Unit: degree.
- ✧ *<ERI Mask>*: When the serial port is connected to a peripheral, and the bit for this peripheral is set to 1, the device will report **+RESP:GTERI** instead of **+RESP:GTFRI**. This mask is used to configure whether to report the data from peripherals by **+RESP:GTERI**.
  - Bit 8 for *<Temperature>* field in the report of **+RESP:GTERI**.

#### Note:

#### Check Interval

If *<GPS on Need>* is set to 1 or *<GPS on Need>* is set to 2 without ignition on, according to the value of *<Check Interval>*, the GPS module has two working modes:

- Mode 1: If the *<Check Interval>* is greater than 60 seconds, the terminal will turn off the GPS chip every time after GPS fix finishes in order to save power.
- Mode 2: If the *<Check Interval>* is less than 60 seconds, the terminal will not turn off the GPS chip.

Due to the length limit of the message, make sure that the *<Send Interval>/<Check Interval>* ratio is no more than 15. If the limit is exceeded, the command will be discarded and the previous settings will be kept unchanged.

If the terminal is in "Force on SMS " (*<Report Mode>* = 5) and the *<Send Interval>/<Check Interval>* ratio is greater than 1, the terminal will report only the last position in the fixed time report. This is because only one position could be filled in a single SMS message (160 bytes at most).

#### Working Time of FRI Report

- *<Begin Time>* < *<End Time>*: The FRI report function works in the time period (Begin Time, End Time) every day.
- *<Begin Time>* > *<End Time>*: The FRI report function works from *<Begin Time>* and at *<End Time>* on the following day.
- *<Begin Time>* = *<End Time>*: The FRI report function works the whole day.

#### Scheduled Report Mode

For fixed distance report, fixed mileage report and optimum report, <GPS on Need> must be 0 (Do not turn off GPS chip) or 2 (Do not turn off GPS chip in ignition on state or movement state). For the fixed time report, it doesn't matter whether GPS keeps working.

### Corner Report

Set <GPS on Need> to 0 or 2 to detect turning point. If not, the detection for turning point may not be so accurate and may lead to error in detecting turning point.

The acknowledgement message of the **AT+GTFRI** command:

➤ **+ACK:GTFRI,**

Example:			
<b>+ACK:GTFRI,F50601,015181001707687,,0051,20190906072058,006F\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

## 3.2.4. Alarm Settings

### 3.2.4.1. Geo-Fence Information

The command **AT+GTGEO** is used to configure the parameters of Geo-fence. Geo-fence is a virtual perimeter around a geographic area using a location-based service. When the terminal enters or exits the area, a notification is generated. The notification contains information about the location of the terminal and can be sent to the backend server.

➤ **AT+GTGEO=**

Example:				
<b>AT+GTGEO=gl300m,0,1,114.015821,22.537364,50,30,0,,,,,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
2	GEO ID	1	0 - 19	
3	Mode	1	0 - 3	0
4	Longitude	<=11	(-)XXX.XXXXXX	
5	Latitude	<=10	(-)XX.XXXXXX	
6	Radius	<=7	50 - 6000000(m)	50
7	Check Interval	<=5	0 30 - 86400(sec)	0
8	State Mode	1	0 1	0
9	Reserved	0		

10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		
16	Serial Number	4	(HEX)	
17	Tail Character	1	\$	\$

- ✧ <GEO ID>: A numeral to identify the Geo-fence.
- ✧ <Mode>: A numeral which indicates when to report the notification to the backend server:
  - 0: Disable the Geo-fence on the specified GEO ID.
  - 1: Reports when entering the Geo-fence.
  - 2: Reports when leaving the Geo-fence.
  - 3: Reports when entering or leaving the Geo-fence.
- ✧ <Longitude>: The longitude of a point which is defined as the centre of the circular Geo-fence region. The format is “(-)XXX.XXXXXX” and the value range is from “-180.000000” to “180.000000”. The unit is degree. West longitude is represented as a negative value starting with the minus sign “-” and east longitude is represented as a positive value without “+”.
- ✧ <Latitude>: The latitude of a point which is defined as the centre of the circular Geo-fence region. The format is “(-)XX.XXXXXX” and the value range is from “-90.000000” to “90.000000”. The unit is degree. South latitude is represented as a negative value starting with the minus sign “-” and north latitude is represented as a positive value without “+”.
- ✧ <Radius>: The radius of the circular Geo-fence region. The value range is (50 -6000000) and the unit is meter.
- ✧ <Check Interval>: The checking interval for the Geo-fence alarm.
- ✧ <State Mode>: A numeral to indicate the mode of reporting the device’s state.
  - 0: The device should report its state when getting the state for the first time.
  - 1: The device doesn’t report its state until the state changes.

**Note:** If the parameter <Check Interval> is set to 0, <Mode> will be set to 0 automatically (For Geo-fence ID 0, <Mode> will be restored first so it could be used later when Geo-Fence ID 0 is enabled via Function Key). This is because the terminal doesn’t know when to check Geo-fence if the parameter <Check Interval> is 0.

The acknowledgement message of the **AT+GTGEO** command:

➤ **+ACK:GTGEO,**

Example:			
<b>+ACK:GTGEO,F50601,015181001707687,,0,0058,20190906072259,0074\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	

Device Name	20		
GEO ID	1	0 - 4	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.4.2. Speed Alarm

The **AT+GTSPD** command is used to configure the speed alarm function of the device. Based on the working mode setting, the device will report speed alarm when its speed is outside or inside a predefined range.

#### ➤ AT+GTSPD=

Example:				
AT+GTSPD=gl300m,1,0,0,60,300,,,,,,,,,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Mode	1	0 1 2	0
3	Min. Speed	<=3	0 - 400(km/h)	0
4	Max. Speed	<=3	0 - 400(km/h)	0
5	Valid Time	<=4	15 - 3600(sec)	60
6	Send Interval	<=4	0 5 - 3600(sec)	300
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Reserved	0		
14	Reserved	0		
15	Reserved	0		
16	Reserved	0		
17	Reserved	0		
18	Reserved	0		
19	Reserved	0		
20	Reserved	0		
21	Reserved	0		
22	Serial Number	4	(HEX)	
23	Tail Character	1	\$	\$

- ✧ **<Mode>**: A numeral to indicate the working modes of speed alarm.
  - 0: Disable speed alarm.
  - 1: Enable speed alarm. If the current speed is within the speed range defined by **<Min. Speed>** and **<Max. Speed>**, a speed alarm is sent.
  - 2: Enable speed alarm. If the current speed is outside the speed range defined by **<Min. Speed>** and **<Max. Speed>**, a speed alarm is sent.
- ✧ **<Min. Speed>**: The lower limit of the speed range.
- ✧ **<Max. Speed>**: The upper limit of the speed range.
- ✧ **<Valid Time>**: If the speed is in a specified speed range and is maintained for a period of time specified by **<Duration>**, the speed alarm will be triggered.
- ✧ **<Send Interval>**: If the speed alarm is triggered, the speed alarm message will be sent periodically according to **<Send Interval>**. If the send interval is set to 0, the speed alarm message will be sent only once.

**Note:** The parameters **<Duration>** and **<Send Interval>** are invalid when GPS is not working. If GPS is not working, the device will report speed alarm immediately when the speed of the terminal is detected to be outside the allowed speed range.

The acknowledgement message of the **AT+GTSPD** command:

➤ **+ACK:GTSPD,**

Example:			
<b>+ACK:GTSPD,F50601,015181001707687,,006D,20190906072756,0095\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.4.3. Temperature Alarm

The **AT+GTTEM** command is used to configure the temperature alarm function of the device. Based on the working mode, the device will report temperature alarm when its temperature is outside or inside a predefined range.

➤ **AT+GTTEM=**

Example:				
<b>AT+GTTEM=gl300m,1,0,0,60,300,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default

1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
2	Mode	1	0 1 2 3	0
3	Min. Temperature	<=3	-20(°C) - 60(°C)	0
4	Max. Temperature	<=3	-20(°C) - 60(°C)	0
5	Duration	<=4	0 - 3600(sec)	60
6	Send Interval	<=4	0 5 - 3600(sec)	300
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Reserved	0		
13	Serial Number	4	(HEX)	
14	Tail Character	1	\$	\$

- ✧ <Mode>: A numeral to indicate the working mode of the temperature alarm function.
  - 0: Disable this function.
  - 1: Report the alarm message **+RESP:GTTEM** when the current temperature is lower than the temperature specified by <Min. Temperature>.
  - 2: Report the alarm message **+RESP:GTTEM** when the current temperature is inside the temperature range.
  - 3: Report the alarm message **+RESP:GTTEM** when the current temperature is higher than the temperature specified by <Max. Temperature>.
- ✧ <Min. Temperature>: The lower limit of the temperature range.
- ✧ <Max. Temperature>: The upper limit of the temperature range.
- ✧ <Duration>: If the temperature is in the specified temperature range and is maintained for a period of time specified by <Duration>, the temperature alarm will be triggered.
- ✧ <Send Interval>: If the temperature alarm is triggered, the temperature alarm message will be sent periodically according to <Send Interval>. If the <Send Interval> is set to 0, the temperature alarm message will be sent only once.

The acknowledgment message of the **AT+GTTEM** command:

➤ **+ACK:GTTEM,**

Example:			
<b>+ACK:GTTEM,F50601,015181001707687,,006E,20190906072819,0097\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_',	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	

Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.5. IO Application

#### 3.2.5.1. Digital Input Port Settings

##### ➤ AT+GTDIS

Example: AT+GTDIS=gl300m,1,0,5,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Input ID	1	1	1
3	Mode	1	0 1 2 3	0
4	Debounce Time	<=2	0 - 20 (*10ms)	5
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ <Input ID>: The ID of the digital input. It is always 1.
- ✧ <Mode>: A numeral to decide whether to enable the digital input.
  - 0: Disable the digital input. The status change of the digital input will be ignored.
  - 1: Enable the digital input. If the status of the input changes, the device will report the message **+RESP:GTDIS** to the backend server to indicate the latest status.
  - 2: If the status of the input is changed to 0, the device will disable the sleep mode. If the status of the input is changed to 1, the device will enable the sleep mode.
  - 3: If the status of the input is changed to 0, the SOS event will be triggered.
- ✧ <Debounce Time>: The time for the input to debounce.

The acknowledgment message of the **AT+GTDIS** command:

##### ➤ +ACK:GTDIS,

Example: +ACK:GTDIS,F50601,015181001707687,,006F,20190906072848,0099\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	

Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6. Other Settings

#### 3.2.6.1. Real Time Operation

The **AT+GTRTO** command is used to retrieve information from the terminal or control the terminal.

#### ➤ AT+GTRTO=

Example:				
AT+GTRTO=gl300m,0,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Sub Command	<=2	0 - F   12 - 13	
3	Single Command Configuration   Configuration Mask	3	0000000000000000 - FFFFFFFFFFFFFFF	
4	Reserved	0		
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Serial Number	4	(HEX)	
9	Tail Character	1	\$	\$

- ✧ **<Sub Command>**: A numeral to indicate the sub command to be executed.
- 0: **(GPS)**: Request GPS related information, including settings of **<GPS on Need>**, **<Report Item Mask>**, **<Report Mask>** of fixed report, GPS antenna type, GPS antenna status and the time of last known successful GPS fix.
  - 1: **(RTL)**: Request the device to report its current position.
  - 2: **(READ)**: Request the device to report its entire configuration.
  - 3: **(REBOOT)**: Reboot the device remotely.
  - 4: **(RESET)**: Reset all parameters to factory defaults except the parameters of **AT+GTBSI**, **AT+GTSRI**, and **AT+GTTMA**.
  - 5: **(PWROFF)**: Power off the device remotely.
  - 6: **(CID)**: Request the device to report the ICCID of the installed SIM card.
  - 7: **(CSQ)**: Request the device to report the current Network signal level.
  - 8: **(VER)**: Request the device to report version information including the device type,

the firmware version, and the hardware version.

9: **(BAT)**: Request the device to report power supply related information including the external power supply status, the current voltage of the battery, the battery charging status and the working mode of LED.

A: **(TMZ)**: Request the device to report the time zone setting.

B: **(INF)**: Request the device information report. The corresponding information will be reported via the message **+RESP:GTINF**.

C: (RESERVED)

D: **(AIF)**: Get APN, ICCID, base station ID, RSSI, cell ID, IP and DNS server network type via **+RESP:GTAIF**.

E: **(GSV)**: Request the device to report the GPS fix level. The corresponding information will be reported via the message **+RESP:GTGSV**

✧ *<Single Command Configuration/Configuration Mask>*:

- AT Command: To get a single AT command's configuration when *<Sub Command>* is set to 2, follow the format in the following example. For example, to get the configuration of **AT+GTFRI**, please set **AT+GTRTO=gl300m,2,FRI,,,,,0015\$**, and get it via **+RESP:GTALS**.
- Configuration Mask: If *<Sub Command>* is set to 2, the configuration information of the specified *<Configuration Mask>* can be obtained via the message **+RESP:GTALC**. The Configuration Mask must be 16 bytes. If it's less than 16 bytes, '0' will be added in the high bytes of the Configuration Mask.
- If *<Sub Command>* is set to 2, and this parameter field is left empty, the device will report all the configurations via **+RESP:GTALC**.

**Configuration Mask Table:**

Mask Bit	Item
Bit 63	Reserved
Bit 62	Reserved
⋮	Reserved
Bit 19	LWM
Bit 18	GAM
Bit 17	PDS
Bit 16	UPC
Bit 15	TEM
Bit 14	WLT
Bit 13	DOG
Bit 12	OWH

<b>Bit 11</b>	PIN
<b>Bit 10</b>	GLM
<b>Bit 9</b>	FKS
<b>Bit 8</b>	NMD
<b>Bit 7</b>	SPD
<b>Bit 6</b>	GEO
<b>Bit 5</b>	FRI
<b>Bit 4</b>	TMZ
<b>Bit 3</b>	DIS
<b>Bit 2</b>	CFG
<b>Bit 1</b>	SRI
<b>Bit 0</b>	BSI

The acknowledgement message of the **AT+GTRTO** command:

➤ **+ACK:GTRTO,**

<b>Example:</b>			
<b>+ACK:GTRTO,F50601,015181001707687,,READ,0070,20190906073020,009F\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Sub Command	<=6	Sub command string	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.2. Data Transfer Between UART and Backend Server

The **AT+GTDAT** command is used to transfer data between UART and the backend server.

➤ **AT+GTDAT=**

<b>Example:</b>				
<b>AT+GTDAT=gl300m,0,,0,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m

2	Command Type	1	0 1	0
3	Reserved	0		
4	Data	<=200	(ASCII)	
5	Need Ack	1	0 1	0
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Serial Number	4	(HEX)	
10	Tail Character	1	\$	\$

- ✧ <Command Type>: A numeral to indicate the way to transfer data.
  - 0: The data should be transferred from UART to the backend server.
  - 1: The data should be transferred from the backend server to UART.
- ✧ <Data>: The data to be transferred. It should be a printable ASCII string.
- ✧ <Need ACK>: A numeral to indicate whether the device should reply **+ACK** message to the backend server.
  - 0: Do not send **+ACK:GTDAT** to the backend server.
  - 1: Send **+ACK:GTDAT** to the backend server.

The acknowledgment message of the **AT+GTDAT** command:

➤ **+ACK:GTDAT,**

Example:			
<b>+ACK:GTDAT,F50601,015181001707687,,0072,20190906073156,00A7\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.3. White Number List Configuration

The **AT+GTWLT** command is used to set up the white number list.

➤ **AT+GTWLT=**

Example:				
<b>AT+GTWLT=gl300m,1,1,1,,,,,FFFF\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m

2	Number Filter	1	0 1 2	1
3	Phone Number Start	1	1 - 10	
4	Phone Number End	1	1 - 10	
5	White Number List	<=20*10		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ **<Number Filter>**: A numeral to indicate whether to filter the original number according to **<White Number List>** and **<Direct Number List>** before sending an SMS with a Google Maps link to the original number.
  - 0: Do not return a Google Maps link via SMS to the original number. Ignore the event of **Position Request** message received no matter whether the original number is in the **<White Number List>** or **<Direct Number List>** or not.
  - 1: Do not filter the original number. It will return a Google Maps link via SMS to the original number as long as it receives **Position Request** message via SMS.
  - 2: Filter the original number. If the original number isn't in **<White Number List>** or **<Direct Number List>**, the device won't return a Google Maps link to the original number even if the device receives **Position Request** message via SMS.
- ✧ **<Phone Number Start>**: A numeral to indicate the first index of the White Number List numbers to be input. For example, if it is **1**, the device will update the White Number List from the **1st** number. If it is empty, there should be no **<White Number List>**.
- ✧ **<Phone Number End>**: A numeral to indicate the last index of the White Number List numbers to be input. For example, if it is **2**, the device will update the whitelist numbers until the **2nd** one. If it is empty, there should be no **<White Number List>**.
- ✧ **<White Number List>**: A White Number List of phone numbers. Two adjacent phone numbers are separated with ",". The number of the phone numbers in the list is determined by the parameters **<Phone Number Start>** and **<Phone Number End>**. For example, if **<Phone Number Start>** is **1** and **<Phone Number End>** is **2**, the **<White Number List>** should include **2** phone numbers and the two numbers are separated by ",".

The acknowledgment message of the **AT+GTWLT** command:

➤ **+ACK:GTWLT**

<b>Example:</b>			
<b>+ACK:GTWLT,F50601,015181001707687,,0086,20190906073850,00C3\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	

Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:** Make sure the size of the command is not greater than 160 bytes if it is sent via SMS.

#### 3.2.6.4. Settings for SMS with Google Maps Link

The **AT+GTGLM** command is used to configure whether to send an SMS with a Google Maps link for SOS and GEO events.

##### ➤ AT+GTGLM=

Example:				
AT+GTGLM=gl300m,1,1,1,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Google Mode	1	0 1 2	0
3	Phone Number Start	1	1 - 3	
4	Phone Number End	1	1 - 3	
5	Direct Number List	<=20*3		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Reserved	0		
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

✧ <Google Mode>: A numeral to indicate whether to send an SMS with a Google Maps link to the number in <Direct Number List> for SOS and GEO events.

- 0: Do not send an SMS with a Google Maps link to the number in the <Direct Number List> for SOS and GEO events.
- 1: Send an SMS with a Google Maps link including the terminal name to the number in the <Direct Number List> for SOS and GEO events.
- 2: Send an SMS with a Google Maps link not including the terminal name to the number in the <Direct Number List> for SOS and GEO events.

✧ <Phone Number Start>: A numeral to indicate the first index of the direct numbers to be input. For example, if it is **1**, the device will update the direct number list from the **1st** number. If it is empty, there should be no <Direct Number List>.

✧ <Phone Number End>: A numeral to indicate the last index of the direct numbers to be input. For example, if it is **2**, the device will update the direct number list until the **2nd** one. If it is empty, there should be no <Direct Number List>.

✧ <Direct Number List>: A list of phone numbers. Two adjacent phone numbers are separated

with ",". The number of the phone numbers in the list is determined by the parameters <Phone Number Start> and <Phone Number End>. For example, if <Phone Number Start> is 1 and <Phone Number End> is 2, the <Direct Number List> should include 2 phone numbers and the two numbers are separated by ",".

The acknowledgment message of the **AT+GTGLM** command:

➤ **+ACK:GTGLM,**

Example:			
<b>+ACK:GTGLM,F50601,015181001707687,,0073,20190906073241,00AB\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.5. Over-the-Air Configuration Update

The **AT+GTUPC** command is used to download configuration file over the air for the update of the local configuration.

➤ **AT+GTUPC=**

Example:				
<b>AT+GTUPC=gl300m,0,10,0,1,0,http://218.17.46.11:9180/GL300M/deltabin/1234.ini,1,,,FFF</b>				
<b>F\$</b>				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z'	gl300m
2	Max Download Retries	1	0 - 3	0
3	Download Timeout	<=2	5 - 30(min)	10
4	Download Protocol	1	0	0
5	Enable Report	1	0 1	0
6	Update Interval	1	0 - 8760	0
7	Download URL	<=100	URL	
8	Mode	1	0 1	0
9	Reserved	0		
10	Reserved	0		
11	Reserved	0		
12	Serial Number	4	0000 - FFFF	
13	Tail Character	1	\$	\$

- ✧ **<Password>**: The valid characters for the password include '0'-'9', 'a'-'z', and 'A'-'Z'. The default value is "gl300m".
- ✧ **<Max Download Retries>**: It specifies the maximum number of retries to download the configuration file upon downloading failure.
- ✧ **<Download Timeout>**: If downloading is not finished within this time, it will be regarded that the downloading failed.
- ✧ **<Download Protocol>**: The protocol used to download the file. Only HTTP is supported now. It is set to 0.
- ✧ **<Enable Report>**: A numeral to indicate whether to send the message **+RESP:GTUPC** to indicate the configuration is updated over the air.
  - 0: Do not report the message **+RESP:GTUPC**.
  - 1: Report the message **+RESP:GTUPC**.
- ✧ **<Update Interval>**: The time interval in (hour) for updating the configuration over the air.
- ✧ **<Download URL>**: It specifies the URL to download the configuration file. If the URL ends with "/", it means it is a path without any file name. <(IMEI)>.ini will be added as the file name at the end of URL.
- ✧ **<Mode>**: A numeral to indicate the working mode of downloading configuration over the air.
  - 0: Disable this function.
  - 1: Enable this function.

The acknowledgement message of the **AT+GTUPC** command:

➤ **+ACK:GTUPC**

Example:			
<b>+ACK:GTUPC,F50601,015181001707687,,0074,20190906073419,00B0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	IMEI	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:**

- (1) If the **<Download URL>** ends with "/", it means it is a path without any file name. <(IMEI)>.ini will be added as the file name at the end of URL. If it is larger than 100, an error will be reported.
- (2) The maximum size of configuration file is 32\*200 bytes. If the size of configuration file is larger than 32\*200 bytes, configuration file cannot be downloaded.
- (3) The length of a command should not exceed 200 bytes in the configuration file.
- (4) Make sure there's only one command per line in the configuration file and there should be a "\r\n" between each command.

### 3.2.6.6. Preserve Device Special Logical State

The command **AT+GTPDS** is used to preserve special logic state of the terminal. Enable the function according to the working mode, and save the logic state according to the value of the *<Mask>*.

#### ➤ AT+GTPDS=

**Example:**  
**AT+GTPDS=gl300m,1,69,,,,,,FFFF\$**

SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9' 'a' - 'z' 'A' - 'Z'	gl300m
2	Mode	1	0 1 2	1
3	Mask	8	00000000 - FFFFFFFF	69
4	Reserved			
5	Reserved			
6	Reserved			
7	Reserved			
8	Reserved			
9	Reserved			
10	Serial Number	4	(HEX)	
11	Tail Character	1	\$	\$

- ✧ *<Mode>*: The working mode of the **AT+GTPDS** command.
  - 0: Disable this function.
  - 1: Preserve special logic state of the device according to the value of the *<Mask>*.
  - 2: Reset all the special logical states listed in the *<Mask>* after receiving the command, and then preserve special logic state of the device according to the value of the *<Mask>*.
- ✧ *<Mask>*: Bitwise mask to configure which device states will be preserved. Each bit represents a state.
  - Bit 0: States of GEO
  - Bit 1: Device reset type. The device will not send **+RESP:GTPFA**, **+RESP:GTPNA**/**+RESP:GTPNL** messages when rebooted by **RTO** or **DOG**.
  - Bit2: Reserved
  - Bit 3: Information of last known position
  - Bit 4: Current device state, including ignition state and motion state
  - Bit 5: State of external power supply
  - Bit 6: State of charge
  - Bit7: State of digital inputs

- Bit20: State in the command **AT+GTL**SW from EBK
- Bit21: State in the command **AT+GTT**SW from EBK
- Bit22: State in the command **AT+GT**OMS from EBK

The acknowledgment message of the **AT+GTPDS** command:

➤ **+ACK:GTPDS,**

Example:			
<b>+ACK:GTPDS,F50601,015181001707687,,0075,20190906073507,00B4\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	IMEI	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_' '?'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.7. GPS-Assisted Motion Measurement

The command **AT+GTGAM** is used for assisting in measuring motion with GPS if the sensor detects motionless state while the vehicle is ignition on.

➤ **AT+GTGAM=**

Example:				
<b>AT+GTGAM=gl300m,1,1,25,10,60,60,,,,,FFFF\$</b>				
SN	Parameter	Length(byte)	Range/Format	Default
1	Password	4 - 20	'0' - '9' 'a' - 'z' 'A' - 'Z'	gl300m
2	Mode	1	0 1	1
3	Speed Mode	1	0 1	1
4	Motion Speed Threshold	<=2	0 - 50(km/h)	25
5	Motion Cumulative Time	<=3	10 - 100(sec)	10
6	Motionless Cumulative Time	<=3	10 - 250(sec)	60
7	GPS Fix Failure Timeout	<=4	5 - 1800(sec)	60
8	Reserved	0		
9	Reserved	0		

10	Reserved	0		
11	Reserved	0		
	Serial Number	4	(HEX)	
	Tail Character	1	\$	\$

- ✧ <Mode>: The working mode of the GPS-assisted motion measurement function.
  - 0: Disable this function.
  - 1: Enable this function.
- ✧ <Speed Mode>: It combines with GPS speed to measure the status of movement.
  - 0: Disable the function.
  - 1: Enable the function.
- ✧ <Motion Speed Threshold>: The speed threshold which is combined with GPS speed to measure the status of movement.
- ✧ <Motion Cumulative Time>: If the average speed in <Motion Cumulative Time> is higher than <Motion Speed Threshold>, the device is considered to be in motion status.
- ✧ <Motionless Cumulative Time>: If the average speed in <Motionless Cumulative Time> is lower than <Motion Speed Threshold>, the device is considered to be in motionless status.
- ✧ <GPS Fix Failure Timeout>: If the time of GPS fix is more than <GPS Fix Failure Timeout>, the device will update motion status by motion sensor again.

The acknowledgment message of the **AT+GTGAM** command:

➤ **+ACK:GTGAM,**

Example:			
<b>+ACK:GTGAM,F50601,015181001707687,,0087,20190906073959,00C6\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9' 'a' - 'z' 'A' - 'Z'	
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.8. Command String Storage

The **AT+GTCMD** command is used to store the commands which will be used by the command **AT+GTUDF**.

➤ **AT+GTCMD=**

Example: AT+GTCMD=gl300m,1,0,AT+CFUN=4,,,,,FFFF\$				
SN	Parameter	Length (Byte)	Range/Format	Default
1	Password	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '_', '_'	gl300m
2	Mode	1	0 - 1	0
3	Stored cmd ID	3	0 - 31	
4	Command String	200	AT command	
5	Reserved	0		
6	Reserved	0		
7	Reserved	0		
8	Reserved	0		
9	Serial Number	4	(HEX)	
10	Tail Character	1	\$	\$

- ✧ <Mode>: The treating method of the command string.
  - 0: Delete the stored command.
  - 1: Add the stored command.
- ✧ <Stored cmd ID>: A numeral to identify the stored command.
- ✧ <Command String>: The whole content of the stored command. The command should end with '\$'.

➤ **+ACK:GTCMD,**

Example: +ACK:GTCMD,F50601,015181001707687,,0079,20190906073622,00B8\$			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	IMEI	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.9. User Defined Function

The **AT+GTUDF** command is used to bind input events and the stored commands. The input events will trigger the corresponding stored commands.

➤ **AT+GTUDF=**

<b>Example:</b>			
<b>AT+GTUDF=gl300m,1,0,100000000,0,0,0,1,0,,,,,FFFF\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
Mode	1	0 - 2	0
Group ID	2	0 - 31	
Input ID Mask	16	0 - FFFFFFFF	
Debounce Time	5	0 - 86400(s)	0
Inzizo Mask	5	0 - FFFFF	0
Outzizo Mask	5	0 - FFFFF	0
Stocmd ID Mask	16	0 - FFFFFFFF	
Stocmd Ack	1	0 1	0
Reserved			
Serial Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ **<Mode>**: The working mode of the user defined function.
  - 0: Disable the group.
  - 1: Enable the group.
  - 2: Delete the group.
- ✧ **<Group ID>**: A numeral to identify the group of input events and stored commands to be executed.
- ✧ **<Input ID Mask>**: The bitwise mask to indicate the input events that included in the group.
  - Bit 0 (00000001): Select ID1
  - Bit 1 (00000002): Select ID2
  - Bit 2 (00000004): Select ID3
  - Bit 3 (00000008): Select ID4
 For example:
  - Bit (00000003): Select ID1, and ID2
  - Bit (00000017): Select ID1, ID2, ID3, and ID5

ID	Mask Bit	Item
1	Bit 0	Power on finished
2	Bit 1	Ignition on
3	Bit 2	Ignition off
4	Bit 3	The PDP connection is attached
5	Bit 4	The PDP connection is not attached
6	Bit 5	The network is registered
7	Bit 6	The network is not registered

8	Bit 7	Network roaming
9	Bit 8	Network non-roaming
10	Bit 9	SIM card is locked
11	Bit 10	GPS is turned on
12	Bit 11	GPS is turned off
13	Bit 12	The device is stationary
14	Bit 13	The device is moving
15	Bit 14	External charger inserted
16	Bit 15	No external charger
17	Bit 16	The device is charging
18	Bit 17	The device is not charging
19	Bit 18	External battery inserted
20	Bit 19	No external battery
21	Bit 20	Digital input 1 is low
22	Bit 21	Digital input 1 is high
23	Bit 22	SIM card is inserted
24	Bit 23	SIM card is not inserted
25	Bit 24	Reserved
26	Bit 25	Reserved
27	Bit 26	Inside the Geo 0
28	Bit 27	Outside the Geo 0
29	Bit 28	Inside the Geo 1
30	Bit 29	Outside the Geo 1
31	Bit 30	Inside the Geo 2
32	Bit 31	Outside the Geo 2
33	Bit 32	Inside the Geo 3
34	Bit 33	Outside the Geo 3
35	Bit 34	Inside the Geo 4
36	Bit 35	Outside the Geo 4
37	Bit 36	Inside the speed range
38	Bit 37	Outside the speed range
39	Bit 38	Messages need to be sent
40	Bit 39	No messages need to be sent
41	Bit 40	SOS event

- ✧ <Debounce Time>: The debounce time for input events before the specified stored commands are executed.
- ✧ <Inzizo Mask>: The bitwise masks to indicate the input events within the Geo-fence.

ID	Mask Bit	Item
1	Bit 0	Inside the Geo 0
2	Bit 1	Inside the Geo 1
3	Bit 2	Inside the Geo 2

4	Bit 3	Inside the Geo 3
5	Bit 4	Inside the Geo 4
6	Bit 5	Inside the Geo 5
7	Bit 6	Inside the Geo 6
8	Bit 7	Inside the Geo 7
9	Bit 8	Inside the Geo 8
10	Bit 9	Inside the Geo 9
11	Bit 10	Inside the Geo 10
12	Bit 11	Inside the Geo 11
13	Bit 12	Inside the Geo 12
14	Bit 13	Inside the Geo 13
15	Bit 14	Inside the Geo 14
16	Bit 15	Inside the Geo 15
17	Bit 16	Inside the Geo 16
18	Bit 17	Inside the Geo 17
19	Bit 18	Inside the Geo 18
20	Bit 19	Inside the Geo 19

◇ <Outzizo Mask>: The bitwise masks to indicate the input events outside the Geo-fence.

ID	Mask Bit	Item
1	Bit 0	Outside the Geo 0
2	Bit 1	Outside the Geo 1
3	Bit 2	Outside the Geo 2
4	Bit 3	Outside the Geo 3
5	Bit 4	Outside the Geo 4
6	Bit 5	Outside the Geo 5
7	Bit 6	Outside the Geo 6
8	Bit 7	Outside the Geo 7
9	Bit 8	Outside the Geo 8
10	Bit 9	Outside the Geo 9
11	Bit 10	Outside the Geo 10
12	Bit 11	Outside the Geo 11
13	Bit 12	Outside the Geo 12
14	Bit 13	Outside the Geo 13
15	Bit 14	Outside the Geo 14
16	Bit 15	Outside the Geo 15
17	Bit 16	Outside the Geo 16
18	Bit 17	Outside the Geo 17
19	Bit 18	Outside the Geo 18
20	Bit 19	Outside the Geo 19

**Note:** If the <Inzizo Mask> or <Outzizo Mask> is set to 0, please check Bit 26 - Bit 35 in <Input ID

Mask>.

- ✧ <Stocmd ID Mask>: The bitwise masks of the stored command which will be executed after the state of the group becomes TRUE (i.e. all input events included in the group occur).
- ✧ <Stocmd Ack>: A numeral to indicate whether to send an acknowledgement message when a stored command is executed.
  - 0: Do not send an acknowledgement message after a stored command is executed.
  - 1: Send an acknowledgement message after a stored command is executed.

**Note:** Maximum 5 stored commands in a group will be executed.

The acknowledgement message of the **AT+GTUDF** command:

➤ **+ACK:GTUDF**

Example:			
<b>+ACK:GTUDF,F50601,015181001707687,,007E,20190906073729,00BD\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	IMEI	
Device Name	20		
Serial Number	4	(HEX)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

### 3.2.6.10. SMS Position Request

This command can only be sent via SMS, and will enable the device to send SMS message with a Google Maps hyperlink of the current position immediately. Please refer to the Chapter 3.3.6 for details of the position report.

<b>Command Format</b>	<b>get position</b>
<b>Example</b>	get position

**get position:** It's a command string to request the current position.

## 3.3. Report

### 3.3.1. Position Related Report

#### 3.3.1.1. General Position Report

- **+RESP:GTGEO:** The message for **AT+GTGEO**
- **+RESP:GTSPD:** The message for **AT+GTSPD**
- **+RESP:GTSOS:** The message after long pressing the function key if the function key is

- enabled and the mode is SOS mode
- **+RESP:GTRTL:** The message for **AT+GTRTO-RTL**
  - **+RESP:GTPNL:** The first location message after the device powers on
  - **+RESP:GTNMR:** Non-movement is detected by motion sensor according to the setting of **AT+GTNMD**.
  - **+RESP:GTDIS:** The status change of digital input is detected if the parameter *<Enable>* is set to 1 in the command **AT+GTDIS**.
  - **+RESP:GTDG:** The watchdog rebooting message
  - **+RESP:GTIGL:** The location message for ignition on and ignition off
  - **+RESP:GTLOC:** Current location message.

**Example:**

```
+RESP:GTGEO,F50601,015181001707687,,0,1,1,1,0.0,0,123.3,114.015577,22.537246,20190906074358,0460,0000,27BD,0DFC,,100,20190906074359,00E4$

+RESP:GTSPD,F50601,015181001707687,,0,1,1,1,0.0,0,123.3,114.015577,22.537246,20190906074739,0460,0000,27BD,0DFC,,100,20190906074740,00F1$

+RESP:GTSOS,F50601,015181001707687,,0,0,1,1,0.0,265,116.7,114.015807,22.537240,20190906074855,0460,0000,27BD,0DFC,,100,20190906074855,00F8$

+RESP:GTRTL,F50601,015181001707687,,37.1,00,1,1,0.0,0,110.1,114.015730,22.537218,20190906075114,0460,0000,27BD,0DFC,,100,20190906075114,0105$

+RESP:GTPNL,F50601,015181001707687,,0,0,1,1,0.0,0,208.4,114.015584,22.538731,20190906083052,0460,0000,27BD,0DFC,,100,20190906083053,01CD$

+RESP:GTNMR,F50601,015181001707687,,0,00,1,1,0.0,0,182.3,114.015301,22.537341,20190906083306,0460,0000,27BD,0DFC,,100,20190906083307,01DA$

+RESP:GTDG,F50601,015181001707687,,0,0,1,1,0.0,0,70.1,114.015182,22.537003,20190908090041,0460,0000,27BD,0DFC,,100,20190908090042,0784$

+RESP:GTDIS,F50601,015181001707687,gl300m,1,1,1,1,0.0,76,117.8,114.015473,22.537251,20190911031617,0460,0000,27BD,0DFC,0.0,100,20190911111618,004E$

+RESP:GTIGL,F50601,015181001707687,gl300m,0,0,1,2,0.0,76,110.1,114.015607,22.537200,20190911031901,0460,0000,27BD,0DFC,0.0,100,20190911111902,005F$

+RESP:GTLOC,F50601,015181001707687,gl300m,0,0,1,1,0.0,76,95.7,114.015303,22.537100,20190911032658,0460,0000,27BD,0DFC,0.1,100,20190911112659,006F$
```

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	

Device Name	20		
Report ID	1	0 - 20 0.0 - 100.0	
Report Type	1	0 1 2 00 - FF	
Number	<=1	1	
GPS Accuracy	<=2	0 - 50	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Battery Percentage	3	0 - 100	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Report ID>: Report ID is only for **+RESP:GTGEO**, **+RESP:GTDIS** and **+RESP:GTRTL** reports, for **+RESP:GTGEO** report, it means the Group ID of the Geo-fence, for **+RESP:GTDIS** report, it means the digital input ID, for **+RESP:GTRTL** report, it means the temperature (range is 0.0 - 100.0). For other reports, it is always 0.
- ✧ <Report Type>: Report Type is only for below reports. For other reports, it is always 0.
  - For **+RESP:GTGEO**
    - 0: Exit the corresponding Geo-fence
    - 1: Enter the corresponding Geo-fence
  - For **+RESP:GTSPD**
    - 0: Outside the speed range
    - 1: Inside the speed range
  - For **+RESP:GTNMR**

The entering-movement trigger and the report type are in hex format. 4 high bits represent the entering-movement trigger and 4 low bits represent the report type. Entering-movement trigger defines the trigger of the message. There are three meanings as below:

    - 0: Triggered by motion sensor detection (Default)
    - 1: Triggered by the sub command **RTL** of **RTO**
    - 2: Triggered by the command **AT+GTL SW** from EBK

Report type has two meanings below.

    - 0: The state of the device changed from motion to rest
    - 1: The state of the device changed from rest to motion

- For the **+RESP:GTDIS**, it is generated by the digital input.
  - 0: The current logic status of the input port is of low level.
  - 1: The current logic status of the input port is of high level.
- In the ignition on and ignition off message **+RESP:GTIGL**
  - 0: The engine is of ignition on.
  - 1: The engine is of ignition off.
- For **+RESP:GTD0G**
  - 0: Reboot periodically according to the *<Interval>* and *<Time>* settings or upon ignition on or by *<Input ID>*
  - 1: PDP is unable to register or the interaction of messages fails.
  - 2: No Network signal
- For **+RESP:GTSOS** and **+RESP:GTLOC**
  - 0: A normal report when *<Function Key Mode>* is not set to 5 (Mixed mode)
  - 1: The first trigger report after the Function Key Button is pressed when *<Function Key Mode>* in the command *AT+GTFKS* is set to 5 (Mixed mode)
  - 2: The second trigger report after the Function Key Button is pressed when *<Function Key Mode>* in the command *AT+GTFKS* is set to 5 (Mixed mode)
- For **+RESP:GTRTL**
  - 0: The status of the device changed from motion to rest.
  - 1: The status of the device changed from rest to motion.
- ✧ *<Number>*: The number of points in one message. According to the settings of fixed report, there could be up to 15 points in one **+RESP:GTFRI** message. For other reports, this parameter value is always 1. If there is more than 1 points in the report, information from *<GPS Accuracy>* to *<ODO Mileage>* will repeat for each point.
- ✧ *<GPS Accuracy>*: A numeral to indicate the GPS fix status and HDOP of the GPS position. 0 indicates the current GPS fix fails and the last known GPS position is used. A non-zero value (1 - 50) indicates the current GPS fix is successful and represents the HDOP of the current GPS position.
- ✧ *<Speed>*: The speed read from GPS.
- ✧ *<Azimuth>* The azimuth from GPS.
- ✧ *<Altitude>*: The height above sea level from GPS.
- ✧ *<Longitude>*: The longitude of the current position. The format is “(-)XXX.XXXXXX” and the value range is from “-180.000000” to “180.000000”. The unit is degree. West longitude is represented as a negative value starting with the minus sign “-” and east longitude is represented as a positive value without “+”.
- ✧ *<Latitude>*: The latitude of the current position. The format is “(-)XX.XXXXXX” and the value range is from “-90.000000” to “90.000000”. The unit is degree. South latitude is represented as a negative value starting with the minus sign “-” and north latitude is represented as a positive value without “+”.
- ✧ *<GPS UTC Time>*: UTC time from GPS.
- ✧ *<MCC>*: Mobile country code. It is 3-digit in length and ranges from 000-999. If Bit 3 of the field *<Report Composition Mask>* in **AT+GTCFG** is not set to 1, the length of this field is 0 in ASCII format message.
- ✧ *<MNC>*: Mobile network code. It is 3-digit in length and ranges from 000-999. If Bit 3 of the

field *<Report Composition Mask>* in **AT+GTCFG** is not set to 1, the length of this field is 0 in ASCII format message.

- ✧ *<Cell ID>*: Cell ID in hex format.
- ✧ *<ODO Mileage>*: The total mileage. If *<Enable ODO>* is set to 0 in the command **AT+GTCFG**, the field will be empty.
- ✧ *<Battery Percentage>*: The current volume of the battery in percentage.

➤ **+RESP:GTFRI**: Report of **AT+GTFRI**

Example:			
<b>+RESP:GTFRI,F50601,015181001707687,,0,0,1,0,0,0,0,123.3,114.015577,22.537246,20190906074209,0460,00,27BD,0DFC,,100,20190906074337,00E3\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Report ID	1	0 - 4	
Report Type	<=2	0 1 16 17	
Number	<=2	1 - 15	
GPS Accuracy	<=2	0 - 50	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Battery Percentage	3	0 - 100	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ *<Report Type>*: The type of the messages **+RESP:GTFRI**
  - 0: The message is a scheduled position report generated in REST state.
  - 1: Reserve.
  - 16: The message is a scheduled position report generated in MOTION state.
  - 17: The message is a turning point report generated in MOTION state.

➤ **+RESP:GTERI**: Report of **AT+GTERI**

If the **+RESP:GTERI** is enabled, the device will send the message **+RESP:GTERI** to the backend

server.

<b>Example:</b>			
<b>+RESP:GTERI,F50601,015181001707687,gl300m,00000100,0,0,1,2,0.0,0,89.1,114.015245,22.537120,20190911033002,0460,0000,27BD,0DFC,0.1,100,1,35.1,,20190911113003,0075\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
ERI Mask	8	00000000 - FFFFFFFF	
Report ID	1	0 - 4	
Report Type	2	0 1 16 17	
Number	<=2	1 - 15	
GPS Accuracy	<=2	0 - 50	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Battery Percentage	3	0 - 100	
Temperature	Number of sensor	<=2	0 - 10
	Temperature in Celsius	<=5	
	Temperature data	4	0000 - FFFF
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ **<Report Type>**: The type of the report messages **+RESP:GTERI**
  - 0: The message is a scheduled position report generated while in REST state.
  - 1: Reserve.
  - 16: The message is a scheduled position report generated while in MOTION state.
  - 17: The message is a turning point report generated while in MOTION state.
- ✧ **<Number of sensor>**: The number of temperature sensor, the default value is always 1 as the temperature is detected by the internal thermistor only. The following field **<Temperature in Celsius>** means the internal real time temperature of the device, If Bit 8 of **<ERI Mask>** in AT+GTFRI is enabled, the whole part of **<Temperature>** will be displayed, otherwise, this part will not be displayed.
- ✧ **<Temperature in Celsius>**: Temperature value in Celsius.

✧ <Temperature Data>: It indicates the data read from the temperature sensor.

### 3.3.1.2. Location Request Report

➤ +RESP:GTLBC,

Example:			
<b>+RESP:GTLBC,F50601,015181001707687,gl300m,18126107340,1,0,0,0,223.6,114.015619,22.536907,20190911033923,0460,0001,253D,AEC3,0.0,,20190911113924,0088\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Original Number	<=20	phone number	
GPS Accuracy	<=2	0 - 50	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-) XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ <Original Number>: The phone number which initiates this report.

### 3.3.1.3. Location as Centre of Geo-Fence

If function key mode is set to 2 and function key is long pressed to switch on Geo-fence 0, the terminal will start GPS fixing to get the current position as the centre of Geo-fence 0. And after GPS fix finishes, the terminal will report the message **+RESP:GTGCR**.

➤ +RESP:GTGCR,

Example:			
<b>+RESP:GTGCR,F50601,015181001707687,gl300m,3,50,30,1,0,0,0,128.8,114.015508,22.537196,20190911034634,0460,0001,253D,AEC3,0.1,,20190911114635,009F\$</b>			

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Geo Mode	1	0 1 2 3	
Geo Radius	<=7	50 - 6000000(m)	
Geo Check Interval	<=5	0 30 - 86400(sec)	
GPS Accuracy	<=2	0 - 50	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Geo Mode>: The mode of Geo-fence 0. Please refer to the parameter <Mode> in the command **AT+GTGEO**.
- ✧ <Geo Radius>: The radius of Geo-fence 0. Please refer to the parameter <Radius> in the command **AT+GTGEO**.
- ✧ <Geo Check Interval>: The check interval of Geo-fence 0. Please refer to the parameter <Check Interval> in the command **AT+GTGEO**.
- ✧ <Longitude>: The longitude of the current position. If current position fix is successful, this longitude will be used as the centre of Geo-fence 0.
- ✧ <Latitude>: The latitude of the current position. If current position fix is successful, this latitude will be used as the centre of Geo-fence 0.

### 3.3.2. Device Information Report

#### ➤ +RESP:GTINF:

##### Example:

```
+RESP:GTINF,F50601,015181001707687,gl300m,42,89860117851087152093,16,99,1,0.1,,4.18,1,1,0,,,20190911034659,100,,36.7,,,20190911114700,00A0$
```

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	

Unique ID	15	(IMEI)	
Device Name	20		
State	2	21 22 41 42	
ICCID	20		
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
External Power Supply	1	0 1	
Mileage	<=9	0.0 - 4294967.0(km)	
Reserved	0		
Battery Voltage	<=4	0.0 - 4.50V	
Charging	1	0 1	
LED On	1	0 - 2	
GPS On Need	1	0 1 2	
Reserved	0		
Reserved	0		
Last GPS Fix UTC Time	14	YYYYMMDDHHMMSS	
Battery Percentage	3	0 - 100	
Reserved	0		
Temperature	<=5	(-)XX.X	
Reserved	0		
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <State>: The current motion state of the device.
  - 21: The device attached vehicle is ignition on and motionless.
  - 22: The device attached vehicle is ignition on and moving.
  - 41: The device is motionless without ignition on.
  - 42: The device is moving without ignition on.
- ✧ <ICCID>: The ICCID of the installed SIM card.
- ✧ <CSQ RSSI>: The network signal strength level.
- ✧ <CSQ BER>: The quality of the network signal.
- ✧ <External Power Supply>: Whether the external power supply is connected.
  - 0: Not connected
  - 1: Connected
- ✧ <Mileage>: The total mileage, based on <ODO Initial Mileage> in **AT+GTCFG**.
- ✧ <Battery Voltage>: The voltage of the battery.
- ✧ <Charging>: Whether the battery is charging when the external power supply is connected.
  - 0: Not charging
  - 1: Charging
- ✧ <LED On>: The setting of <LED On> in **AT+GTCFG**.
- ✧ <GPS on Need>: The setting of <GPS on Need> in **AT+GTCFG**.

- ✧ <Last GPS Fix UTC Time>: The UTC time of the latest successful GPS fix.
- ✧ <Temperature>: The temperature of the device.

### 3.3.3. Report for Querying

The reports for real time querying via the command **AT+GTRTO** are as follows.

- **+RESP:GTGPS:** The report for the real time operation of the subcommand **GPS**.

Example:			
<b>+RESP:GTGPS,F50601,015181001707687,gl300m,0,8,,3F,,,20190911034843,20190911114844,00A6\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
GPS On Need	1	0 1 2	
GPS Fix Delay	3	5 - 60(sec)	
Reserved	0		
Report Item Mask	<=4	(HEX)	
Reserved	0		
Reserved	0		
Last GPS Fix UTC Time	14	YYYYMMDDHHMMSS	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- **+RESP:GTALC:** The report for the real time operation of the subcommand **READ**. After the device receives the command **AT+GTRTO** to read all the configurations, it will send all configurations to the backend server by the message **+RESP:GTALC**. If the length of the message is greater than 1000 bytes, the **+RESP:GTALC** will be divided into several packets with the <Configuration Mask> indicating the content of each packet. This message is only sent via TCP connection even if the report mode is Force on SMS.

Example:	
<b>+RESP:GTALC,F50601,015181001707687,gl300m,000000000000003F,BSI,555555,34s22s,3444,333,21ss,223,1,0,SRI,3,,1,218.17.46.11,91,218.17.46.11,90,15817439628,0,0,1,,,,CFG,gl300m,gl300m,1,0.1,0,8,003F,0,,3FFF,0,1,1,300,2,0,20491231235959,0,,1,DIS,1,1,5,,,,,TMZ,+0800,0,,,,,FRI,1,0,,,0000,0000,60,60,180,180,,1000,1000,0,5,50,1,0,100,20190911115540,00A9\$</b>	
<b>+RESP:GTALC,F50601,015181001707687,gl300m,0000000000001FC0,GEO,0,3,114.015508,22.537196,50,30,0,,,,,1,0,0.000000,0.000000,50,0,0,,,,,2,0,0.000000,0.000000,50,0,0,,,,,3,0,0.000000,0.000000,50,0,0,,,,,4,0,0.000000,0.000000,50,0,0,,,,,5,0,0.000000,0.000000,50,0,0,,,,,6,0,0.000000,0.000000,50,0,0,,,,,7,0,0.000000,0.000000,50,0,0,,,,,8,0,0.000000,0.000000,50,</b>	

```

0,0,,,,,,,,9,0,0.000000,0.000000,50,0,0,,,,,,,,10,0,0.000000,0.000000,50,0,0,,,,,,,,11,0,0.000000,0.
000000,50,0,0,,,,,,,,12,0,0.000000,0.000000,50,0,0,,,,,,,,13,0,0.000000,0.000000,50,0,0,,,,,,,,14,0,
0.000000,0.000000,50,0,0,,,,,,,,15,0,0.000000,0.000000,50,0,0,,,,,,,,16,0,0.000000,0.000000,50,0
,0,,,,,,,,17,0,0.000000,0.000000,50,0,0,,,,,,,,18,0,0.000000,0.000000,50,0,0,,,,,,,,19,0,0.000000,0.
000000,50,0,0,,,,,,,,SPD,0,0,0,60,300,,,,,,,,NMD,E,2,3,5,10800,10800,2,3,0,0,,,,FKS,1,1,2,1,1,
3,3,4,4,3,GLM,0,,,,,,,,PIN,0,,0,,,,OWH,0,0,0900,1200,1300,1800,,,0,,,,,,,,,20190911115540,00AA
$
+RESP:GTALC,F50601,015181001707687,gl300m,000000000047E000,DOG,0,60,30,0200,,1,0,0,6
0,60,60,,WLT,1,,,,,,,,,TEM,0,0,0,60,300,,,,UPC,0,10,0,1,0,http://szqueclink.f3322.net:9180/
GL300M/deltabin/UPC_1.ini,1,,,,PDS,1,69,,,,,GAM,0,0,25,10,60,60,,,,,NTS,0,0,0,,,,10,,20190911
115540,00AB$
    
```

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Configuration Mask	16	0000000000000000 - FFFFFFFF	
BSI	3	BSI	BSI
APN	<=40		
APN User Name	<=30		
APN Password	<=30		
Backup APN	<=40		
Backup APN User Name	<=30		
Backup APN Password	<=30		
Network Mode	1	0 - 2	0
LTE Mode	1	0 - 3	0
SRI	3	SRI	SRI
Report Mode	1	0 - 7	0
Reserved	0		
Enable Buffer	1	0 1	1
Main Server IP/Domain Name	<=60		
Main Server Port	<=5	0 - 65535	0
Backup Server IP/Domain Name	<=60		
Backup Server Port	<=5	0 - 65535	0
SMS Gateway	<=20		
Heartbeat Interval	<=3	0 10 - 360(min)	0
Enable SACK	1	0 1	0
SMS ACK Enable	1	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		

CFG	3	CFG	CFG
New Password	4 - 20	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	
Device Name	20		gl300m
Enable ODO	1	0 1	0
ODO Mileage	<=9	0.0 - 4294967.0(km)	0.0
GPS On Need	1	0 1 2 3	0
GPS Fix Delay	3	5 - 60(sec)	5
Report Item Mask	<=4	(HEX)	001F
Reserved	0		
Reserved	0		
Event Mask	4	0000 - FFFF	0FFF
EPB mode	1	0 1	0
LED On	1	0 - 2	1
Enable Info Report	1	0 1	1
Info Report Interval	<=5	30 - 86400(sec)	300
Location Request Mask	1	0 - 3	2
Enable Expiry	1	0 1	0
Expiration Time	14	YYYYMMDDHHMMSS	20491231235959
Reserved	0		
Reserved	0		
Battery Switch Power On	1	0 1	0
DIS	3	DIS	DIS
Input ID	1	1	1
Enable	1	0 1	0
Debounce Time	<=2	1 - 20 (*10ms)	5
Reserved	0		
TMZ	3	TMZ	TMZ
Time Zone	5	- +HHMM	
Daylight Saving	1	0 1	
Reserved	0		
FRI	3	FRI	FRI
Mode	1	0 1 2 3 4 5 6	0
Discard No Fix	1	0 1	1
Reserved	0		

Reserved	0		
Begin Time	4	HHMM	0000
End Time	4	HHMM	0000
Check Interval	<=5	5 - 86400(sec)	180
Send Interval	<=5	5 - 86400(sec)	180
Ignition Check Interval	<=5	5 - 86400(sec)	180
Ignition Send Interval	<=5	5 - 86400(sec)	180
Reserved	0		
Distance	<=5	50 - 65535m	1000
Mileage	<=5	50 - 65535m	1000
Movement Detection Mode	1	0 1	0
Movement Speed	<=3	1 - 999((km/h))	5
Movement Distance	<=4	1 - 9999(m)	50
Movement Send Number	1	1 - 5	5
Corner	3	0 - 180	0
ERI Mask	8	00000000 - FFFFFFFF	00000000
GEO	3	GEO	GEO
GEO ID0	<=2	0	0
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(m)	50
Check Interval	<=5	0 30 - 86400(sec)	0
State Mode	1	0 1	0
Reserved	0		
GEO ID1	<=2	1	1
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(m)	50
Check Interval	<=5	0 30 - 86400(sec)	0
State Mode	1	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		

Reserved	0		
⋮	⋮	⋮	⋮
GEO ID18	<=2	18	18
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(m)	50
Check Interval	<=5	0 30 - 86400(sec)	0
State Mode	1	0 1	0
Reserved	0		
GEO ID19	<=2	19	19
Mode	1	0 - 3	0
Longitude	<=11	(-)XXX.XXXXXX	
Latitude	<=10	(-)XX.XXXXXX	
Radius	<=7	50 - 6000000(m)	50
Check Interval	<=5	0 30 - 86400(sec)	0
State Mode	1	0 1	0
Reserved	0		
SPD	3	SPD	SPD
Mode	1	0 1 2	0
Min. Speed	<=3	0 - 400(km/h)	0
Max. Speed	<=3	0 - 400(km/h)	0
Duration	<=4	15 - 3600(sec)	60
Send Interval	<=4	30 - 3600(sec)	300
Reserved	0		
Reserved	0		
Reserved	0		



Direct Number	20		
Reserved	0		
<b>PIN</b>	<b>3</b>	<b>PIN</b>	<b>PIN</b>
Auto Unlock PIN	1	0 1	1
PIN	4- 8	'0' - '9'	
PIN Check	1	0 1	0
Reserved	0		
<b>OWH</b>	<b>3</b>	<b>OWH</b>	<b>OWH</b>
Mode	1	0 1 2 3	0
Day of Work	<=2	0 - 7F	1F
Working Hours Start1	4	HHMM	0900
Working Hours End1	4	HHMM	1200
Working Hours Start2	4	HHMM	1300
Working Hours End2	4	HHMM	1800
Reserved	0		
Reserved	0		
Digital Input ID	1	0 1	0
Reserved	0		
<b>DOG</b>	<b>3</b>	<b>DOG</b>	<b>DOG</b>
Mode	1	0 1 2	0
Ignition Frequency	<=3	10 - 120	60
Interval	<=2	1 - 30(days)	30
Time	4	HHMM	0200
Reserved	0		
Report Before Reboot	1	0 1	1
Input ID	1	0 1	0
Unit	1	0 1	0
Network Interval	4	0 5 - 1440	480
PDP Interval	4	0 5 - 1440	480

Send Fail Timeout	4	0 5 - 1440	480
Reserved	0		
WLT	3	WLT	WLT
Call Filter	1	0 1 2	1
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
White Number List Number	20		
Reserved	0		
TEM	3	TEM	TEM
Mode	1	0 1 2 3	0
Min. Temperature	<=3	-20(°C) - 60(°C)	0
Max. Temperature	<=3	-20(°C) - 60(°C)	0
Duration	<=4	0 - 3600(sec)	60
Send Interval	<=4	0 5 - 3600(sec)	300
Reserved	0		
UPC	3	UPC	UPC
Max. Download Retry	1	0 - 3	0
Download Timeout	<=2	5 - 30(min)	10

Download Protocol	1	0	0
Enable Report	1	0 1	0
Update Interval	1	0 - 8760	0
Download URL	<=100	URL	
Mode	1	0 1	0
Reserved	0		
Reserved	0		
Reserved	0		
<b>PDS</b>	<b>3</b>	<b>PDS</b>	<b>PDS</b>
Mode	1	0 1 2	1
Mask	8	00000000 - FFFFFFFF	69
Reserved			
<b>GAM</b>	<b>3</b>	<b>GAM</b>	<b>GAM</b>
Mode	1	0 1	1
Speed Mode	1	0 1	1
Motion Speed Threshold	<=2	0 - 50(km/h)	25
Motion Cumulative Time	<=3	10 - 100(sec)	10
Motionless Cumulative Time	<=3	10 - 250(sec)	60
GPS Fix Failure Timeout	<=4	5 - 1800(sec)	60
Reserved	0		
<b>NTS</b>	<b>3</b>	<b>NTS</b>	<b>NTS</b>
Enable	1	0 1	0
Rssi threshold	3	0 - 35	30
Interval	3	0 - 300(min)	10
Oper1	10		
Oper2	10		
Oper3	10		
GSM interval	3	0 - 300(min)	10
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

**Note:** Regardless the report mode setting, **+RESP:GTALC** is only reported through TCP/UDP. If current report mode is Force on SMS, **+RESP:GTALC** will still be reported via TCP/UDP.

➤ **+RESP:GTCID:** The report for the real time operation of the subcommand **CID**.

<b>Example:</b>			
<b>+RESP:GTCID,F50601,015181001707687,gl300m,89860117851087152093,20190911115808,00B4\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
ICCID	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTCSQ:** The report for the real time operation of the subcommand **CSQ**.

<b>Example:</b>			
<b>+RESP:GTCSQ,F50601,015181001707687,gl300m,11,99,20190911115837,00B6\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTVER:** The report for the real time operation of the subcommand **VER**.

<b>Example:</b>			
<b>+RESP:GTVER,F50601,015181001707687,gl300m,GL300M,0802,0106,0000,BG96,BG96MAR02A07M1G,20190911115908,00B8\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Device Type	10	'0' - '9', 'a' - 'z', 'A' - 'Z', '-', '_'	gl300m
Firmware Version	4	(HEX)	
Hardware Version	4	(HEX)	
Reserved	4	0000	0000
Modem Hardware Version	<=20		

Modem Software Version	<=50		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Device Type>: A string which represents the type of the device.
- ✧ <Firmware Version>: The firmware version of the device. The first two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ <Hardware Version>: The hardware version of the device. The first two characters indicate the major version and the last two characters indicate the minor version. For example, 010A means version 1.10.
- ✧ <Modem Hardware Version>: It gives the modem hardware information of this device.
- ✧ <Modem Software Version>: It gives the modem software version information of this device.

- **+RESP:GTBAT:** The report for the real time operation of the subcommand **BAT**.

Example:			
<b>+RESP:GTBAT,F50601,015181001707687,gl300m,1,,100,4.19,1,1,20190911115945,00BA\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
External Power Supply	1	0 1	
Reserved	0		
Battery Percentage	3	0 - 100	
Battery Voltage	<=4	0.0 - 4.50V	
Charging	1	0 1	
LED On	1	0 - 2	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- **+RESP:GTTMZ:** The report for the real time operation of the subcommand **TMZ**.

Example:			
<b>+RESP:GTTMZ,F50601,015181001707687,gl300m,+0800,0,20190911120008,00BC\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Time Zone Offset	5	+/- HHMM	
Daylight Saving	1	0 1	
Send Time	14	YYYYMMDDHHMMSS	

Count Number	4	(HEX)	
Tail Character	1	\$	\$

- **+RESP:GTALS:** The report for the real time operation of the subcommand **READ** (e.g. DIS).

<b>Example:</b>			
<b>+RESP:GTALS,F50601,015181001707687,g 300m,DIS,1,1,5,,,,,20190911134609,010F\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
DIS	3	DIS	DIS
Input ID	1	1	1
Mode	1	0 1 2 3	0
Debounce Time	<=2	0 - 20 (*10ms)	5
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- **+RESP:GTAIF:** After the device receives the command **AT+GTRTO** to get the AIF, it will send the information via the message **+RESP:GTAIF** to the backend server.

<b>Example:</b>			
<b>+RESP:GTAIF,F50601,015181001707687,g 300m,555555,34s22s,3444,3333,21ss,223,89860117851087152093,19,99,AEC3,10.228.45.8,,,,,0,20190911135211,0116\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	<=20	'0' - '9', 'a' - 'z', 'A' - 'Z', '.', '_'	
APN	<=40		
APN User Name	<=30		
APN Password	<=30		
Backup APN	<=40		
Backup APN User Name	<=30		
Backup APN Password	<=30		

ICCID	20		
CSQ RSSI	<=2	0 - 31 99	
CSQ BER	<=2	0 - 7 99	
Cell ID	<=8		
IP Address	7	0.0.0.0	
Main DNS	7	0.0.0.0	
Backup DNS	7	0.0.0.0	
Reserved			
Reserved			
Reserved			
Network Type	1	-1,0,2	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ <CSQ RSSI>: The signal strength level.

CSQ RSSI	Signal Strength (dBm)
0	<-133
1	-111
2 - 30	-109 - -53
31	>-51
99	Unknown

✧ <CSQ BER>: The quality of the network signal. The range is 0 -7, and 99 is for unknown signal strength.

✧ <Cell ID>: The cell ID (in hex format) of the serving cell.

✧ <IP Address>: The IP address of the device.

✧ <Main DNS>: The main DNS server.

✧ <Backup DNS>: The backup DNS server.

✧ <Network Type>: The type of the mobile network the device is currently registered on.

- -1: Unregistered
- 0: GSM
- 2: Cat-M1/Cat-NB1/LTE

➤ **+RESP:GTGSV**: After the device receives the command to get satellite information, it will send the satellite information via the message +RESP:GTGSV to the backend server.

**Example:**

<b>+RESP:GTGSV,F50701,015181001708016,,11,2,11,3,10,4,0,5,22,6,30,9,14,12,34,17,35,19,30,23,20,28,13,20190916094936,3E2C\$</b>			
<b>Parameter</b>	<b>Length (Byte)</b>	<b>Range/Format</b>	<b>Default</b>
Protocol Version	6	XX0000 – XXXFFF, X ∈ {'A' – 'Z','0' – '9'}	
Unique ID	15	IMEI	
Device Name	<=20	'0' – '9' 'a' – 'z' 'A' – 'Z' '-' '_'	
SV Count	2	0-24	
SV ID	2	>= 0	
SV Power	2	>= 0	
... ..			
SV ID	2		
SV Power	2		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 – FFFF	
Tail Character	1	\$	\$

- ✧ <SV Count>: The count of satellites the GPS finds.
- ✧ <SV ID>: The satellite ID. In case of no satellite, the field is filled with zero.
- ✧ <SV Power>: Satellite power. In case of no satellite, the field is filled with zero.

### 3.3.4. Event Report

The following event reports are triggered when certain events occur.

- +RESP:GTPNA:** Power on report
- +RESP:GTPFA:** Power off report
- +RESP:GTEPN:** The report for connecting external power supply
- +RESP:GTEPF:** The report for disconnecting external power supply
- +RESP:GTBPL:** Battery low report
- +RESP:GTBTC:** Start charging report
- +RESP:GTSTC:** Stop charging report
- +RESP:GTSTT:** Device motion state indication
- +RESP:GTPDP:** PDP connection report
- +RESP:GTSWG:** Enable or disable Geo-fence ID 0 via function key
- +RESP:GTIGN:** Ignition on report
- +RESP:GTIGF:** Ignition off report
- +RESP:GTTEM:** Temperature alarm report
- +RESP:GTUPC:** Configuration updated report

In **+RESP:GTEPN**, **+RESP:GTEPF**, **+RESP:GTBTC**, **+RESP:GTSTC**, **+RESP:GTBPL**, **+RESP:GTSTT**, and **+RESP:GTSWG** event reports, the last known GPS information and the current network information are included.

➤ **+RESP:GTPNA,**

<b>Example:</b>			
<b>+RESP:GTPNA,F50601,015181001707687,gl300m,20190911135351,0119\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTPFA,**

<b>Example:</b>			
<b>+RESP:GTPFA,F50601,015181001707687,gl300m,20190911135337,0118\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTEPN,**

<b>Example:</b>			
<b>+RESP:GTEPN,F50601,015181001707687,gl300m,1,0.0,0,210.5,114.016051,22.539205,20190911055726,0460,0001,253D,AEC3,0.1,20190911135727,012B\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	

MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Last Longitude>: The longitude of the last position. The format is “(-)XXX.XXXXXX” and the value range is from “-180.000000” to “180.000000”. The unit is degree. West longitude is represented as a negative value starting with the minus sign “-” and east longitude is represented as a positive value without “+”.
- ✧ <Last Latitude>: The latitude of the last position. The format is “(-)XX.XXXXXX” and the value range is from “-90.000000” to “90.000000”. The unit is degree. South latitude is represented as a negative value starting with the minus sign “-” and north latitude is represented as a positive value without “+”.

➤ **+RESP:GTEPF,**

**Example:**  
**+RESP:GTEPF,F50601,015181001707687,g|300m,1,0.0,0,238.3,114.016303,22.539099,20190911055554,0460,0001,253D,AEC3,0.1,20190911135554,0122\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTBPL,**

<b>Example:</b>			
<b>+RESP:GTBPL,F50601,015181001707687,,3.48,0,0,0,0,178.4,114.015571,22.537409,20190906013759,0000,0000,0000,0000,,20190906155248,0639\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Battery Voltage	<=4	0.0 - 4.50V	
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTBTC,**

<b>Example:</b>			
<b>+RESP:GTBTC,F50601,015181001707687,gl300m,1,0,0,0,210.5,114.016051,22.539205,20190911055726,0460,0001,253D,AEC3,0.1,20190911135727,012C\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	

LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTSTC,**

**Example:**

**+RESP:GTSTC,F50601,015181001707687,g|300m,,1,0.0,0,238.3,114.016303,22.539099,20190911055554,0460,0001,253D,AEC3,0.1,20190911135555,0123\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Reserved	0		
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTSTT,**

**Example:**

**+RESP:GTSTT,F50601,015181001707687,g|300m,41,1,0.0,40,212.0,114.016205,22.539455,20190911055755,0460,0001,253D,AEC3,0.2,20190911135756,012E\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
State	2	21 22 41 42	
GPS Accuracy	1	0	

Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTPDP,**

**Example:**

**+RESP:GTPDP,F50601,015181001707687,gl300m,20190911135513,011E\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

➤ **+RESP:GTSWG,**

**Example:**

**+RESP:GTSWG,F50601,015181001707687,gl300m,0,3,0.0,40,234.9,114.015705,22.538426,20190911060133,0460,0001,253D,AEC3,0.3,20190911140134,0135\$**

Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Geo Activation	1	0 1	
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	

MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ *<Geo Activation>*: A numeral to indicate whether to activate or deactivate Geo-fence 0 by long pressing the function key.

- 0: Deactivate Geo-fence 0.
- 1: Activate Geo-fence 0.

➤ **+RESP:GTIGN,**

<b>Example:</b>			
<b>+RESP:GTIGN,F50601,015181001707687,g 300m,0,2,0.0,76,110.1,114.015607,22.537200,20190911031901,0460,0000,27BD,0DFC,0.0,20190911111901,005D\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Duration of Ignition Off	<=6	0 - 999999 sec	
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

✧ *<Duration of Ignition Off>*: Duration since ignition off. If it is greater than 999999 seconds, 999999 seconds will be reported.

## ➤ +RESP:GTIGF,

Example:			
<b>+RESP:GTIGF,F50601,015181001707687,gl300m,6,2,0.0,76,110.1,114.015607,22.537200,20190911031906,0460,0000,27BD,0DFC,0.0,20190911111907,0061\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Duration of Ignition On	<=6	0 - 999999 sec	
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	
Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	0 4	0XXX	
MNC	0 4	0XXX	
LAC	0 4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Duration of Ignition On>: Duration since last ignition on. If it is greater than 999999 seconds, 999999 seconds will be reported.

## ➤ +RESP:GTTEM,

Example:			
<b>+RESP:GTTEM,F50601,015181001707687,gl300m,2,38.1,1,0.0,0,225.9,114.015488,22.538050,20190911062008,0460,0001,253D,AEC3,0.3,20190911142009,014F\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Alarm Type	1	1 2 3	
Temperature	<=5	(-)XX.X	
GPS Accuracy	1	0	
Speed	<=5	0.0 - 999.9(km/h)	

Azimuth	<=3	0 - 359	
Altitude	<=8	(-)XXXXX.X(m)	
Last Longitude	<=11	(-)XXX.XXXXXX	
Last Latitude	<=10	(-)XX.XXXXXX	
GPS UTC Time	14	YYYYMMDDHHMMSS	
MCC	4	0XXX	
MNC	4	0XXX	
LAC	4	(HEX)	
Cell ID	<=8	(HEX)	
ODO Mileage	9	0.0 - 4294967.0(km)	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Last Longitude>: The longitude of the last position. The format is “(-)XXX.XXXXXX” and the value range is from “-180.000000” to “180.000000”. The unit is degree. West longitude is represented as a negative value starting with the minus sign “-” and east longitude is represented as a positive value without “+”.
- ✧ <Last Latitude>: The latitude of the last position. The format is “(-)XX.XXXXXX” and the value range is from “-90.000000” to “90.000000”. The unit is degree. South latitude is represented as a negative value starting with the minus sign “-” and north latitude is represented as a positive value without “+”.
- ✧ <Alarm Type>: The type of the temperature alarm.
  - 1: The current temperature is lower than the value specified by <Min. Temperature>.
  - 2: The current temperature is within the temperature threshold range.
  - 3: The current temperature is higher than the value specified by <Max. Temperature>.
- ✧ <Temperature>: The current temperature of the device.

➤ **+RESP:GTDAT,**

Example:			
<b>+RESP:GTDAT,F50601,015181001707687,gl300m,SSDXDDS,20190911142124,0152\$</b>			
Parameter	Length (Byte)	Range	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Data	4	0XXX	
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4		
Tail Character	1	\$	\$

- ✧ <Data>: The data to be transferred when the command **AT+GTDAT** is executed. It should be

a printable ASCII string.

➤ **+RESP:GTUPC,**

**Example:**

**+RESP:GTUPC,F50601,015181001707687,gl300m,0,100,http://szqueclink.f3322.net:9180/GL300M/deltabin/UPC\_1.ini,20190911142238,0155\$**

Parameter	Length(Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20	'0' - '9', 'a' - 'z', 'A' - 'Z'	
Command ID	1		
Result	2	100 101 102 103 200 201 202 300 301 302	
Download URL	<=100	URL	
Reserved	0		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	0000 - FFFF	
Tail Character	1	\$	\$

- ✧ **<Command ID>**: The command ID in the update configuration file. It is always 0 before the device starts to update the configuration. It indicates the total number of the commands when the response result code is 301. It indicates wrong format of command ID when the response result code is 302.
- ✧ **<Result>**: A numeral to indicate whether the configuration is updated successfully.
  - 100: The update command is starting.
  - 101: The update command is confirmed by the device.
  - 102: The update command is refused by the device.
  - 103: The update process is refused because the battery is low.
  - 200: The device starts to download the package.
  - 201: The device finishes downloading the package successfully.
  - 202: The device fails to download the package.
  - 300: The device starts to update the device configuration.
  - 301: The device finishes updating the device configuration successfully.
  - 302: The device fails to update the device configuration.
- ✧ **<Download URL>**: The URL to download the configuration. It includes the file name.

### 3.3.5. Buffer Report

If the buffer function is enabled, the terminal will save the messages into the buffer in the following circumstances.

- ✧ No network signal.
- ✧ Failed to activate network context for the TCP or UDP connection.
- ✧ Failed to establish TCP connection with the backend server.
- ✧ The buffered messages' header will be "+BUFF" instead of "+RESP" if device reboot occurs,

for example, reboot caused by watchdog or manual reboot.

The buffered messages will be sent to the backend server when connection to the server recovers. The buffer reports are saved to the built-in non-volatile memory in case the device is reset. The device can save 10000 messages at most.

- ✧ Only **+RESP** messages except **+RESP:GTALC** and **+RESP:GTPDP** can be buffered.
- ✧ In the buffer report, the original header string “**+RESP**” is replaced by “**+BUFF**”. Other contents such as the original sending time and count number remain unchanged.
- ✧ Buffered messages will be sent only via Network by TCP or UDP protocol. They cannot be sent via SMS.
- ✧ The buffered messages will be sent after the real-time messages if *<Buffer Mode>* in **AT+GTSRI** is set to 1.
- ✧ The buffered messages will be sent before the real-time messages if *<Buffer Mode>* in **AT+GTSRI** is set to 2. The SOS message has the highest priority and is sent before the buffered messages.

#### Example:

The following is an example of the buffered message:

```
+BUFF:GTFRI,F50601,015181001707687,gl300m,0,16,1,1,0,0,0,225.9,114.015488,22.538050,20190911062436,0460,0001,253D,AEC3,0,0,100,20190911142438,0161$
```

### 3.3.6. Report with Google Maps Hyperlink

According to the settings of the command **AT+GTGLM** or upon receiving **SMS Position Request** message via SMS, the device can send an SMS with a Google Maps hyperlink to a mobile phone.

If the device receives **SMS Position Request** message via SMS, GL300M Series will send its current position to the original number via SMS with a Google Maps hyperlink if the original number is a direct number (please refer to *<Direct Number List>* in the Chapter 3.2.6.4) or a number in the White Number List (please refer to *<White Number List>* in the Chapter 3.2.6.3).

If the *<Google Link Mode>* in the command **AT+GTGLM** is set to 1, GL300M Series will send an SMS with a Google Maps hyperlink to the direct phone numbers after the messages **+RESP:GTSOS** and **+RESP:GTGEO**.

#### ➤ Google Maps Hyperlink

Example:			
gl300m SOS:			
<a href="http://maps.google.com/maps?q=22.538503,114.017054+%28gl300m%29">http://maps.google.com/maps?q=22.538503,114.017054+%28gl300m%29</a>			
F1 D2019/09/11T14:33:05 B100%			
Parameter	Length (Byte)	Range/Format	Default
SMS Header	<=30		
Google Maps Hyperlink	<=77		
GPS Fix	2	F1 F0	

GPS UTC Time	20	DYYYY/MM/DDTHH:MM:SS	
Battery Level	<=5	B1 - 100(%)	

- ✧ <SMS Header>: A string that includes the terminal name and GPS fix type ("SOS", "IN GEO-i", "OUT GEO-i", "LBC").
- ✧ <Google Maps Hyperlink>: A string which represents a Google Maps hyperlink.

### 3.4. Heartbeat

Heartbeat is used to maintain the contact between the device and the backend server via network communication. The heartbeat package is sent to the backend server at the interval specified by <Heartbeat Interval> in the **AT+GTQSS** or **AT+GTSRI** command.

#### ➤ +ACK:GTHBD,

Example:			
<b>+ACK:GTHBD, F50601, 015181001707687,, 20190911142438,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Unique ID	15	(IMEI)	
Device Name	20		
Send Time	14	YYYYMMDDHHMMSS	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

Whenever the backend server receives a heartbeat package, it should reply with an acknowledgement message to the device.

#### ➤ +SACK:GTHBD,

Example:			
<b>+SACK:GTHBD,F50601,11F0\$</b>			
Parameter	Length (Byte)	Range/Format	Default
Protocol Version	6	(HEX)	
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ <Count Number>: The backend server uses the <Count Number> extracted from the heartbeat package from the device as the <Count Number> in the server acknowledgement of the heartbeat package.

### 3.5. Sever Acknowledgement

If server acknowledgement is enabled by the **AT+GTQSS** or **AT+GTSRI** command, the backend server will reply to the device whenever it receives a message from the device.

➤ **+SACK:**

Example:			
+SACK:11F0\$			
Parameter	Length (Byte)	Range/Format	Default
Count Number	4	(HEX)	
Tail Character	1	\$	\$

- ✧ *<Count Number>*: The backend server uses the *<Count Number>* extracted from the received message as the *<Count Number>* in the server acknowledgement.

## 4. Appendix: Message Index

### ✧ Command and ACK

AT+GTBSI

+ACK:GTBSI

AT+GTSRI

+ACK:GTSRI

AT+GTQSS

+ACK:GTQSS

AT+GTCFG

+ACK:GTCFG

AT+GTPIN

+ACK:GTPIN

AT+GTDG

+ACK:GTDG

AT+GTTMA

+ACK:GTTMA

AT+GTNMD

+ACK:GTNMD

AT+GTFKS

+ACK:GTFKS

AT+GTOWH

+ACK:GTOWH

AT+GTNTS

+ACK:GTNTS

AT+GTFRI

+ACK:GTFRI

AT+GTGEO

+ACK:GTGEO

AT+GTSPD

+ACK:GTSPD

AT+GTTEM

+ACK:GTTEM

AT+GTDIS

+ACK:GTDIS

AT+GTRTO

+ACK:GTRTO

AT+GTDAT

+ACK:GTDAT

AT+GTWLT

+ACK:GTWLT

AT+GTGLM

+ACK:GTGLM

AT+GTUPC

+ACK:GTUPC  
AT+GTGAM  
+ACK:GTGAM  
AT+GTCMD  
+ACK:GTCMD  
AT+GTUDF  
+ACK:GTUDF  
AT+GTPDS  
+ACK:GTPDS

✧ **Position Related Report**

+RESP:GTFRI  
+RESP:GTGEO  
+RESP:GTSPD  
+RESP:GTSOS  
+RESP:GTRTL  
+RESP:GTPNL  
+RESP:GTNMR  
+RESP:GTDIS  
+RESP:GTDG  
+RESP:GTIGL  
+RESP:GTGCR  
+RESP:GTLBC  
+RESP:GTLOC

✧ **Device Information Report**

+RESP:GTINF

✧ **Report for Querying**

+RESP:GTGPS  
+RESP:GTALC  
+RESP:GTCID  
+RESP:GTCSQ  
+RESP:GTVR  
+RESP:GTBAT  
+RESP:GTTMZ  
+RESP:GTALS  
+RESP:GTAIF  
+RESP:GTGSV

✧ **Event Report**

+RESP:GTPNA  
+RESP:GTPFA  
+RESP:GTEPN

+RESP:GTEPF  
+RESP:GTBPL  
+RESP:GTBTC  
+RESP:GTSTC  
+RESP:GTSTT  
+RESP:GTPDP  
+RESP:GTSWG  
+RESP:GTIGN  
+RESP:GTIGE  
+RESP:GTTEM  
+RESP:GTUPC

✧ **Data Transfer Command Report**

+RESP:GTDAT

✧ **Heartbeat**

+ACK:GTHBD

+SACK:GTHBD

✧ **Server Acknowledgement**

+SACK